

Heartland
AG SYSTEMS

EQUIPMENT

MT24

SERIES

TENDERS

2024 AND OLDER

**OPERATOR'S MANUAL
AND PARTS LIST
OM-MT24**

HEARTLAND AG SYSTEMS
1180 STATE HWY 7 EAST
HUTCHINSON, MN. 55350
(320) 587-4030

ISSUE
AUGUST 2025

WARRANTY REGISTRATION

TO THE DEALER:

Inspect the implement thoroughly after assembly to be certain it is functioning properly before delivering it to the customer. Check off each item as it is found satisfactory or after proper adjust is made.

PRE -DELIVERY CHECKLIST

- _____ 1. All hardware properly tightened.
- _____ 2. Lubrication of grease fittings.
- _____ 3. All decals properly located and readable.
- _____ 4. Other adjustments, "level operation", "drawbar height", etc.
- _____ 5. Proper tongue weight after all options are mounted.
Adjustments made if required.
- _____ 6. Overall condition. Touch-up paint any scratches. Clean and polish
- _____ 7. Operator's manual.

Review the operator's manual with the customer. Explain the following:

- _____ 1. Safe operation and service
- _____ 2. Correct machine installation and operation.
- _____ 3. Correct and periodic lubrication and maintenance.
- _____ 4. Daily and periodic inspection.
- _____ 5. Troubleshooting.
- _____ 6. Storing machine.
- _____ 7. Heartland AG Systems parts and service
- _____ 8. Have the customer write the machine model and serial number in the space provided in the manual introduction
- _____ 9. Give the customer the operator's manual and encourage the customer to read the manual carefully.

Seller Information	
Date set-up	_____
Signature	_____
Dealer name	_____
Address	_____
City, state, zip	_____
Phone	_____

Customer Information	
Date delivered	_____
Customer name	_____
Customer address	_____
Signature	_____
Model number	_____
Serial number	_____

CONTENTS

To The Owner	2
Warranty	W1-8
Safety Instructions	5 - 13
Safety Decals	14 & 15
Operating The Tender	16 & 17
Maintenance and Servicing	18 & 19
PARTS	
Dimensional Specs.- 16 Ft. Auger	20
Dimensional Specs.- 13 Ft. Auger	21
Mounting Instructions for Trailer mount version	22
Mounting Instructions to a Truck Chassis	23
Ladder Mounting Instructions	24
Notes:	25
Decals	26 & 27
Basic Unit, (Body and Frame)	28 - 30
Auger Assemblies	31 & 32
Lowering Auger	33 & 34
Hydraulic Plumbing, Basic	35 & 36
Valve- (4) Bank (Used with Kohler Engines)	37
Hydraulic Plumbing, w/frnt mnt cntrl valve	38 & 39
Engine Drive Package (30 HP Kohler)	40 & 41
Engine Drive Retro-fit Package (30 HP Kohler)	42
Rear Mounted Drivers Side Controls Hyd Schematic	42A
Hyd. Plbg, Front Mounted Drivers side controls	43
Engine Drive Package (Kohler 37hp)	44 & 44A
Engine Drive Package (Deutz 46.2 hp)	45 & 46
Engine Drive Package (Deutz 74 hp)	45A-51A
Valve-V20 (5) Bank (for Duetz Eng Drives)	46B
Std. Hydraulic Plumbing,w/Duetz Engine Drive	47
Hyd. Plbg, Retro-fit, Direct to Duetz Eng. Drv.	48
Install Lockout Valve Feature to 2014 and older	49
Hyd. Plbg, Front Mounted Engine and Hydraulic Controls Driver side Rear with Deutz 46.2hp PP	50
Hyd. Plbg, Front Mt Drivers side controls w Deutz	51
Body Extension Kits	52
Catwalk Assemblys (Optional)	53
Catwalk Installation Instructions	54
Catwalk Platform Bolt on Safety Instructions	54A & B
Light Kit Illustration	55
Roll Top Parts List (Shur-Lok)	56 & 57
Vibrator Parts	58 & 59

TO THE OWNER

Congratulations on your selection of the Heartland AG Systems Tender.

The Heartland AG Systems Tender has been designed to provide years of profitable and dependable service. To assure maximum performance of your Tender it is mandatory that you thoroughly study the operator's manual and follow its recommendations. Proper operation and maintenance are essential for safety and to maximize machine life.

It is the owner, manager, and/or operators' responsibility to:

Operate and maintain this tender in a safe manner and in accordance with all applicable local, state, and federal codes and or laws; and in compliance with labeling instructions by the supplier of the chemicals being used.

Make sure each and every operator has read this manual and thoroughly understands safe and correct operating procedure.

Make sure unauthorized people neither operate the Tender nor are in the vicinity of the Tender while it is in operation.

Make sure the Tender is maintained to preserve and/or improve safety, accuracy, and reliability of the system. Read and follow the maintenance schedule in this manual. Furthermore, as additional technology becomes available, the owner is responsible for improving the safety, accuracy, and reliability of the Tender.

Fulfill all warranty obligations so as not to void the warranties. The warranty information on the following pages outlines the warranty policy of Heartland AG Systems and its suppliers.

Heartland Ag Systems; dba Heartland Agriculture, LLC reserves the right to make product improvements to the equipment at any time. Heartland AG Systems shall not be obligated to make such changes to the machines already in service.

Warranty Policies and Terms

The Heartland Agriculture, LLC warranty is a limited warranty that is provided to the retail purchaser in return for consideration paid as part of the purchase price for a product. The selling dealer must review the warranty coverage with the retail purchaser and obtain a signature on the Operators Manual for warranty verification.

The warranty described here is for Heartland Agriculture, LLC doing business as Heartland AG Systems and its product line Heartland AG Systems Equipment sold and registered in the United States and Canada and normally operated in the United States and Canada.

Warranty Period

The warranty period for all coverage begins at the time that any person, dealer or agent first places the unit into service. At the latest, a unit is placed into service when purchased or delivered to a purchaser.

What's Covered

If a defect in material or workmanship is found in a unit and reported during the Warranty period, Heartland AG Systems will pay parts and labor costs to repair the defects if the services are performed by an authorized Heartland AG Systems dealer. If parts are needed during the repair, Heartland AG Systems will, at its option, use genuine Heartland AG Systems, or remanufactured parts.

Heartland AG Systems provides no warranty, express or implied, for a component or other item that is separately warranted to the purchaser by its manufacturer, such as tires. Check with your local dealer for these details.

Exclusive Remedy

The remedy of repairing a defect in material or workmanship at a Heartland AG Systems dealership under the terms of this warranty is the purchaser's exclusive remedy and is in lieu of any other remedy otherwise available.

No Modification or Extension of Warranty

The Heartland AG Systems Warranty is limited to the written terms in the warranty statement. Heartland AG Systems does not authorize any person, dealer, or agent to change or extend the terms of this warranty in any manner. Any assistance to the purchaser in the repair or operation of any Heartland AG Systems product outside the terms or limitations or exclusions of this warranty will not constitute a waiver of the terms, limitations or exclusions of this warranty, nor will such assistance extend or re-establish the warranty.

The warranty is void if the unit is used in an application for which it is not designed or the unit has been scrapped, salvaged, stolen, junked or totaled.

Limitations and Exclusions

The Heartland AG Systems warranty gives you specific legal rights and you may also have other rights, which vary from state to state. This section contains the entire Heartland AG Systems warranty. Heartland AG Systems makes no other representations or warranties, expressed or implied, and specifically excludes the implied warranties of merchantability and fitness for particular purpose. Heartland AG Systems will not be liable for incidental or consequential damages resulting from a breach of the written warranty or any implied warranty.

- These limitations and exclusions may not be allowed by some states or provinces and shall not apply to the extent such limitations or exclusions are not allowed by applicable state/provincial law.

Owner's Responsibility

The Heartland AG Systems Warranty remains in effect during the warranty period if the owner performs the required maintenance at the recommended intervals outlined in the product's operator's manual and the unit is operated within its rated capacity. Genuine Heartland AG Systems service parts or Heartland AG Systems approved service parts that meet Heartland AG Systems specifications must be used for maintenance and repairs.

What Is Not Covered

- Replacement of non-defective wear items expected to be replaced during the warranty period, including, but not limited to: lights, fuses, belts, drive sprockets and chains, hose, soil engaging tools, spray tips, fertilizer deflectors, spinner blades and accessories or items replaced due to customer demand.
- Normal maintenance parts and service, including, but not limited to lubrication, coolants, and filters.
- All travel costs associated with hauling or towing a customer's machine to and from a repair center related to any warranty repair unless specifically covered by a program or policy.
- Repairs arising from any unauthorized modification to the product.
- Repairs arising from service performed by agents not approved by Heartland AG Systems.
- Repairs arising from storage deterioration, failure to maintain the equipment, improper use of the equipment, collision or other accident, vandalism, or other casualty, or operation beyond the rated capacity or specifications.
- Repairs arising from abuse or neglect including, but not limited to operation without adequate lubricants or coolant, over-speeding, contaminated fluids, improper storage, starting, warm-up, or shutdown practices.
- Failure of the machine, its implements or attachments caused by improper field application or overloading.
- Premiums charged for over-time labor costs.
- Economic loss, including lost profits, crop loss, equipment rental or other expenses.
- Cost associated with cleaning of machine in preparation for service.
- Loss or damage during shipment.

- Cost of initial setup or installation of any optional equipment or attachments to a unit.
- Items used for repairs include, but are not limited to: solvents, cleaners, anti-seize lubricants, oil-dry, shop towels, shop supplies, special tools, etc.
- Included, but not limited to are checkups, adjustments, and shimming, tune-ups, spread pattern checks, etc.
- Unauthorized modification or field fixes.
- All costs of special tools or shop supplies incurred with repairs.
- Claims for stolen equipment or parts.
- Claims for replacing a complete assembly when the repair is less than the replacement.
- Claims involving the inspection or reconditioning of units.
- Shop comebacks: any duplicate, repeat, or comeback repair resulting from improper diagnosis, testing, or poor service work.
- Cost of removing or installing Non-Heartland AG Systems optional equipment or attachments.

Base Warranty Coverage

- Base Warranty is the factory warranty provided to the customer at no additional cost for a specific period covering the complete machine.

• Liquid Applicators, except tires	1 Year
• Spreaders and Tenders, except tires	1 Year
• Nh3 Wagons, except tires	1 Year
• Bumper Hitches	1 Year
• Disc Covers	1 Year
• Parts	90 Days
• Tandem Wagons (except tires and main frame)	1 year
o Tandem Wagon main frame	5 Years
• Nitromaster Toolbars shall carry the following pro-rated warranty:	
o Year one, all components except tires	100%
o Year two, center section and wings	80%
o Year three, center section and wings	50%
o Year four, center section and wings	25%
o Year five, center section and wings	10%

Tires

Tires installed on all Heartland AG Systems Equipment are warranted and serviced by their manufacturer's service outlets. Some manufacturers have separate service outlets for off road agricultural and construction equipment. Service is available by contacting the tire manufacturer's local representative.

Warranty Registration

All machinery items, which are invoiced by Heartland AG Systems on separate receivables, must be registered for warranty. The warranty period for all coverage begins at the time that any person, dealer, or agent first places the unit into service. New machine warranty coverage begins when the machine is registered. Registration is accomplished when a properly completed Warranty Registration is received and processed by Heartland AG Systems.

Operator's Manual/Warranty Receipt Verification

The Heartland AG Systems New Equipment Limited Warranty for Agricultural Equipment statement must be filled out and signed by the customer indicating receipt and an understanding of the operator's manual and the warranty statement,

- The original form must be mailed to the address on the form.
- Make one copy for the Dealer. This copy must be retained by your dealership the same as any other legal document.
- Make a second copy for the customer.

Heartland AG Systems Responsibility

If a defect in material or workmanship is found in a product during its warranty period, Heartland AG Systems will pay parts and labor costs to repair the defect when the service is performed by an authorized Heartland AG Systems dealer or agent. If parts are needed during the repair, Heartland AG Systems will, at its option, use genuine Heartland AG Systems new or remanufactured parts. These responsibilities include, but are not limited to:

- Costs for repairs that are the result of defects in material and workmanship
- Payment to dealers per policy in a timely manner
- Service information to dealers
- Identify product deficiencies and take corrective action by field campaigns
- Make determination of premature wear
- Provide unit that is free of defects in material & workmanship

Dealer Responsibility

Heartland AG Systems dealers are responsible for providing prompt, courteous, and willing service to all Heartland AG Systems equipment owners. These responsibilities include but are not limited to:

- Equipment set-up and pre-delivery
- Sell the right product for the intended application
- Inspect the unit and initiate recovery action on any shipping damage and or shortages
- Instruct customer on proper use, maintenance, and safety features of machine
- Advise and explain warranty coverage to customer
- Diagnose the problem, repair the unit, and submit claims in accordance with the terms and conditions of the warranty claim policies
- Take responsibility for saying "NO" to customers on non-warranty failures
- Apply failure analysis to questionable repairs
- Complete product update campaigns
- Have properly trained technicians and adequate tools for the job
- Retain proper documentation of failure repaired

Owners Responsibility

The Heartland AG Systems warranty remains in effect during the stated warranty period if the owner performs the required maintenance at the recommended times as outlined in the products operator's manual. Genuine Heartland AG Systems or Heartland AG Systems approved service parts must be used for maintenance. Additionally, the owner will pay for all transportation or travel expenses related to any warranty repair.

These responsibilities include, but are not limited to:

- Perform maintenance as indicated in the operator's manual
- Use the unit in the correct application (non-abusive)
- Notify dealer of failures and have the machine available for repair in a timely manner
- Training operators
- Travel cost, towing charges, and service calls
- Normal wear items
- Machine damage (accidental)
- Adjustments for application
- Machine inspection (daily walk-around)

Warranty Eligibility

The dealer is responsible to determine that any Heartland AG Systems equipment is covered by Heartland AG Systems warranty before performing a repair and that the repair is a warrantable failure. Any dealer who is in doubt of the equipment's warranty eligibility may call Heartland AG Systems for verification.

Warranty Repairs Made by the Customer

If a Heartland AG Systems dealer determines that the customer is capable, and the customer requests permission to perform select(warranty)repairs on his product, the Heartland AG Systems dealer is authorized to grant this customer request. The servicing dealer should provide the parts to the customer upon request, and to assure that customer is properly instructed on how to perform the repairs correctly.

The servicing dealer is responsible and accountable for claim accuracy and validity; specifically, in areas such as the parts replaced date, and assurances that the parts are installed as instructed by Heartland AG Systems. The comments section of the claim should clearly state that the customer installed the parts. The claim reimbursement will be for parts and applicable handling only. No labor is allowed! All replacement parts must be held for possible recall.

Parts Shortages on Whole-Goods

Dealers may submit a claim for parts shortages discovered during pre-delivery or during final assembly at the dealer's location. All claims for shortages must be submitted 5 days from the original ship date from the plant and before the warranty start date.

Warranty Reimbursement Policies

Heartland AG Systems provides for warranty reimbursement due to defects in material or workmanship only. Warranty does not include restoring any machine or portion thereof, which has accumulated hours of operation, to factory new condition. This includes customer owned and used equipment.

Except for only a few items not available through Heartland AG Systems, all Heartland AG Systems manufactured equipment warranty repairs must be performed using only Heartland AG Systems genuine new or remanufactured parts and accessories. Installation of non-Heartland AG Systems parts does not qualify for warranty reimbursement and can void the machine's warranty.

Parts

It is fully expected that all claims be filed using part numbers from the applicable Heartland AG Systems equipment parts book whenever such part number exists. Heartland AG Systems shall reimburse the dealer at the dealer net price (cost) in effect on the parts replaced date.

Labor

Heartland AG Systems shall reimburse the dealer at 80% of the dealer's posted retail shop labor rate. The retail shop labor rate shall be subject to verification by Heartland AG Systems from copies of actual dealer invoices to customers.

Outside Charges

Specialized repair such as that done by a machine shop will be accepted as part of a warranty claim at actual cost. Explain the parts used and the service work performed in the description section of the claim and retain a copy of the receipt. Retain a copy of the invoice with the shop work order to support the claim. Outside repairs that exceed the cost of the same repair, if performed by the dealer, will be reimbursed at a lower rate.

Freight



Heartland AG Systems will pay the freight charges when a warranty recalled part is to be returned to Heartland AG Systems.

Travel

Travel will only be reimbursed when authorized by a field campaign.

Repairing or Replacing Parts and Components

When performing a warranty repair, a complete part or component should not be replaced under warranty if the repair can be accomplished at a lower cost. If the total cost of the repair including the cost of parts, labor, and/or outside labor or materials is less than 75% of the cost of the parts, the part must be repaired.

Filters and Lubricants

Replacement of lubricants and filters do not qualify for warranty reimbursement unless damage caused by a defect in material or workmanship results in contamination or sudden loss of fluid. Lack of maintenance, operator misuse, or neglect will not qualify for warranty reimbursement.

Claim Form Guidelines

Claims Must Have

1. Product identification number (PIN) or serial number. All characters of the PIN must be used on the warranty claim.
 - Claims for parts warranty must use the word "PARTS" for the PIN. An invoice that shows date of sale or date of installation must be supplied for all parts claims.
2. Model Number
3. Date of failure – Claims must be submitted within 30 days or repair.
4. Date of repair
5. Warranty start date. Date the unit warranty starts or date the parts were sold for parts warranty.
6. Description of the problem. Describe all problems pertinent to the claim.

Comments should be as precise as possible, attach a separate sheet if necessary, to describe the problem.
7. Description of the work performed. List each significant action of the repair.
8. Itemize labor. Provide a breakdown of labor for each significant repair action in the "Describe Work Performed" column.
9. Shop order numbers. The shop order number field is used for recording your shop work order number that is related to the claim. The shop order number field can also be used to record the parts invoice number when claiming a parts warranty.
10. Customer information. Customer information includes the customer name, city, state, county, and postal code. It must match the warranty registration.
11. Warranty claim total. The total of all reimbursement costs requested.
12. Dealer signature and date. All claims must be signed and dated by the distributor to be validated.

Safety Instructions





THIS MESSAGE ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which, if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates a potentially hazardous situation which, if not avoided will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

98007AG

The following chapter covers recommended safety instructions, along with other general recommendations and specific machine safety precautions that should be read thoroughly before operating the machine.

Safety

Read and comply with the operators manual and safety instructions before operating the machine.

Understand that your safety and the safety of other persons is measured by how you service and operate this machine. Know the positions and operation of all controls before you try to operate. **Make sure you check all controls in a safe area before starting your work.**

Read this manual completely and all other manuals provided with this vehicle, plus make sure you understand the controls. All equipment has a limit. Make sure you understand the speed, brakes, steering, stability, and load characteristics of this machine before you start to operate.

The safety information given in this manual does not replace safety codes, insurance needs, federal, state, and local laws. Make sure your machine has the correct equipment required by local laws and regulations.

Case Corporation is continuing to work for your safety by making tenders with better protection and by giving these rules for safe operation.



WARNING: THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

Personal Safety

Throughout this manual and on the machine's safety decals, you will find precautionary statements: **DANGER, WARNING**, or **CAUTION** followed by specific instructions or ISO two panel safety pictorial symbols. These precautions are intended for your personal safety.

Failure to follow the **DANGER, WARNING**, or **CAUTION** instructions may result in serious bodily injury or death.

- **DANGER:** Indicates an immediate hazardous situation that, if not avoided, will

result in death or serious injury. The color associated with Danger is RED.

- **WARNING:** Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.
- ISO two panel **pictorial symbol decals** are defined as follows:
 - The first panel indicates the nature of the hazard.
 - The second panel indicates the appropriate avoidance of the hazard.
 - Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.

Safety Rules

- DO NOT operate or service this machine unless you have read and understood the Operators Manual and have been properly trained in the machine's operation.
- Before starting the engine, be sure all operating controls are in neutral or park position. This will eliminate accidental movement of the machine or start up of power driven equipment.
- This machine requires an operator at all times. Never leave the machine running and unattended.
- ALWAYS be sure the work area is clear of persons before operating the machine. NEVER allow anyone in the work area during machine operation. DO NOT allow inexperienced persons to operate this machine.
- Sound horn of tow vehicle before operating the machine.
- **No Riders** - A frequent cause of personal injury or death is persons falling off and being run over. Do not permit others to ride.
- For road travel, use flashing warning lamps unless prohibited by law and keep SMV visible.

- ALWAYS put the controls in neutral, shut the engine off, apply the parking brake, and remove the key BEFORE exiting the tow vehicle.
- Extra weight and bad traction conditions, such as mud or ice, increase your stopping distance. Remember, a loaded machine increases the distance needed to stop.
- DO NOT smoke while servicing the machine.
- DO NOT operate the machine while under the influence of alcohol or drugs.
- Hydraulic oil or diesel fuel are high pressured systems. Make sure all lines and fittings are tight and in good condition. These fluids, escaping under pressure, can have sufficient force to penetrate skin and cause serious injury. Failure can result in serious injury or death.
- Escaping hydraulic fluid under pressure can have sufficient force to penetrate skin, causing serious injury. NEVER check for leaks by using any part of your body to feel for escaping fluid.
- Before servicing the machine, make sure the machine has cooled down. Hydraulic components can get hot enough to cause serious injury.
- After servicing the machine ALWAYS replace guards and shields. NEVER operate your machine with guards and shields removed.
- Be aware of all pinch points on the machine and keep clear.
- Keep bolts tight at all times. Always replace worn or broken parts immediately after they are discovered. Do not use the vehicle if any parts are not functioning properly.
- Do not replace parts with other than genuine factory parts. Doing so could decrease the effectiveness of safety features or the accuracy of the machine.
- This machine is designed for the farming industry. Comply with your local and state laws governing weight, lighting, licensing, overhang, bumpers, maximum width, transportation of chemicals, and any other regulations that might apply.

Safety

- When disconnecting battery terminals, remove the Negative (-) cable first; then remove the Positive (+). When connecting cables, connect the Positive (+) first, then connect the Negative (-).
- Disconnect the battery (both terminals) before welding on any part of the machine.

Failure to do so may cause damage to sensitive electrical components.

- **BATTERY ACID CAUSES SEVERE BURNS.** Batteries contain sulfuric acid. Avoid contact with skin, eyes or clothing. Antidote: **EXTERNAL** - flush with water. **INTERNAL** - drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call physician immediately. **EYES** - flush with water for 15 minutes and get prompt medical attention. **BATTERIES PRODUCE EXPLOSIVE GASES.** Keep sparks, flame and cigarettes away. Ventilate when charging or using in enclosed space. Always shield eyes when working near batteries. **KEEP OUT OF REACH OF CHILDREN.**
- When working around stage batteries, remember that all of the exposed metal parts are "live". Never lay a metal object across the terminals because a spark, short circuit, explosion or personal injury may result.

Electrical Line Safety

- Know the area before operating the machine. Be aware of power lines, electrical boxes, debris and rocks.
- Watch for adequate overhead clearance when operating the machine.

Machine Operation and Roll-Over Safety

- **DO NOT** ride or allow other persons to ride on the machine. Riders can fall or can cause an accident.
- **DO NOT** operate the machine while under the influence of alcohol or drugs.
- Be alert and always know the location of all workers in your area. keep all other persons completely away from your machine. Injury or death can result if you do not follow these instructions

Noise Level Safety

- Exposure to high noise levels may cause hearing loss. Wearing suitable hearing protective devices protects against loud noise.

Hazardous Chemicals

- If you are exposed to or come in contact with hazardous chemicals you can be

seriously injured. The fluids, lubricants, paints, adhesives, coolants, etc., used with your machine can be hazardous.

- Material Safety Data Sheets (MSDS) provide information about the chemical substances within a product, safe handling procedures, first aid measures and procedures to be taken when the product is accidentally spilled or released. MSDS are available from your chemical dealer. It is the operator's responsibility to be familiar with the safe handling of the chemical used.
- Before you service your machine, check the MSDS for each fluid, lubricant, etc., used in this machine. This information indicates what the risks are and how to service the machine safely. Follow this information when servicing the machine.
- Before you service this machine and before you dispose of the old fluids and lubricants, always remember the environment. DO NOT put oil or fluids into the ground or into containers that can leak.
- Check with your local environmental or recycling center or your dealer for correct disposal information.
- Personal Protective Equipment (PPE) is protective gear worn by pesticide handlers as specified in the use directions on a pesticide label.

Maintenance Safety

- Before you service the machine, place a Do Not Operate tag on the machine.
- Always keep safety and informational decals clean and visible. Replace decals that are damaged, lost, painted over or can not be read.
- When assembling, operating or servicing the machine, wear protective clothing and personal safety devices that are necessary for the particular procedure. Some personal safety devices that may be necessary are protective shoes, face and/or eye protection, hard hat, heavy gloves, filter mask and hearing protection.
- DO NOT wear jewelry or loose fitting clothing that may get caught in moving parts. Always wear close fitting clothing. Keep hands, feet, clothing and hair away from moving parts.
- Never attempt to clear obstructions or objects from the machine while the engine is running.
- Always stop the engine and remove the key from the key switch when leaving the operators seat or the machine.
- When servicing the machine, always have the machine on a firm level surface.

- If shield or guards are removed or opened for service, always replace them before operating the machine. Never operate the machine with missing or open shields or guards.
- Keep the area used for servicing the machine clean and dry. Wet or oily floors are slippery. Wet spots can be dangerous when working with electrical equipment. Be sure all electrical outlets and tools are properly grounded.

Tire Inflation

Consult your vehicles operator's manual for proper tire inflation.

First Aid Kit

It is recommended that you have a First Aid Kit on the job site and in your maintenance area.

Read Operators Manual

Decals which display the "Read Operators Manual" symbol are intended to direct the operator to the Operators Manual for further information regarding safety, maintenance, adjustments and/or procedures for specific areas of the machine.

When a decal displays symbol shown, refer to the appropriate page of the Operators Manual. Refer to the Detail Index at the end of this manual for locating specific items about your machine.

Fire Extinguisher

It is recommended that you have a fire extinguisher on your machine. A fire extinguisher is available from your dealer and can be installed on your machine.

This dry chemical fire extinguisher is approved for Class A, B and C type fires. The operating temperature is -54° to 49°C (-65° to 120°F).

Hand Signals

It is recommended that all persons on the job site use hand signals for communications. Before you start, make sure all persons understand the signals that will be used.

Start Engine



Stop Engine



227L95

Come To Me

Move hands forward and rearward - palms in



Move Away from Me

Move hands forward and rearward - palms out



228L95

Go This Far



All Stop and Hold



229L95

Stop

Move one hand back and forth



Emergency Stop

Move both hands rapidly back and forth



222L95

Turn Machine Left

To stop movement, stop moving hand and make a fist



Turn Machine Right

To stop movement, stop moving hand and make a fist




225L95



Safety Decals

Check and replace any worn, torn, hard to read, or missing safety decals on your machine

Safety Decal Pictorials



Safety Decal Pictorials - continued



Your MT16 tender is designed to be mounted on a chassis for over-the-road transportation of granular fertilizer and chemicals. Comply with all local, state, and federal codes, laws, and /or regulations including, but not limited to:

- vehicle weight, height restrictions, and bumper, brake, and light requirements



Warning: Always wear proper personal protective equipment (PPE) when handling herbicides and other chemicals.



Caution: Fertilizer is very corrosive. Over time it will oxidize steel. This weakens steel parts and can cause possible safety hazards. Periodically check safety shields and structural members for corrosion. Replace or repair anything that could cause a potential safety hazard.

Operating Instructions



Operating Instructions

This chapter starts with a pre-operation checklist. Then it explains certain parts of the machine and how they operate. It also presents detailed instructions for the first time operators.

Pre-Operation Checklist



Inspect unit

- Be sure all shipping fasteners are removed
- Check tender thoroughly for screws, bolts, fittings, etc., which may have come loose during shipping.

Transporting

Before transporting the unit, make sure it is secured to the truck bed, trailer, etc. Be sure that that the tarp and auger are properly secured in place. Make sure the auger is in the “DOWN” position before transporting.

Operating the Tender

Truck Hydraulic

The hydraulic pump should supply 22 gallons per minute (GPM). Auger speed on the hydraulic unit is approximately 375 revolutions per minute (RPM). Specify PTO pump based on truck transmission and desired engine RPM's.

Engine/Hydraulic

Follow the engine manufacturer's recommendations in the maintenance manual. Check to see the engine has proper oil level before starting.

Operating Instructions


Unit

Make sure the auger is in the down position before transporting the tender. See that the cleanout door is shut and properly secured before loading. Always have the auger running before opening the hopper gate. Always shut the gate and empty the auger before shutting the auger off.

Auger

Units equipped with cable guide type of alignment

- Do not operate auger in the down position. Damage to the cable guide will result.
- Check set screws that hold cable guide in place. If they become loose the guide will slip down into the lower screw.





When raising and lowering auger

- Feather the hydraulic cylinder at the end of the stroke to prevent damage to auger, screw, or cradle.

On augers equipped with shaft and bushing type alignment

- Check alignment on upper and lower screw when raising the auger.



Maintenance and Servicing



Daily Machine Maintenance

Overnight Storage

Avoid overnight storage of material in machine if at all possible.

Build-up Of Material

Hosing the machine out with water after each day's use will eliminate build-up if this is done before the material has hardened. The auger may be cleaned by unloading dry gravel or similar abrasive materials. Stainless units should be washed regularly, especially 409 stainless because fertilizers containing chlorides will pit and discolor the metal.



Caution: All residue that is washed off the tender must be disposed of in accordance with local, state, and federal EPA regulations.

Tarp

Loosen the tarp or open Flip top (or Roll tarp) so any excess moisture can escape.

Weekly Machine Maintenance

Greasing

Grease all fittings every 75 hours of operation. Use only one (1) pump of a standard grease gun per application. DO NOT USE AN AIR GUN.



Important: Do not over-grease. Over-greasing will break the seals on the bearings and allow fertilizer and dirt into the bearing; thereby, causing bearing failure.

Between Season Maintenance

Hopper Body

Clean all the old fertilizer out of the unit and wash it down thoroughly. Touch up with a rust preventative paint where needed. Clean and lubricate guides for hopper gates.

Auger

Clean auger by running coarse gravel or some other abrasive material through auger until cleaned. Be sure the clean out door is left open.



Caution: All residue that is washed off the tender must be disposed of in accordance with local, state, and federal EPA regulations.

Unit



- Remove the tarp or open and secure Flip top (or Roll tarp) to prevent moisture from being trapped inside the hopper.
- If equipped with engine, remove the battery and store inside.
- If stored outside, cover the engine with a cover or tarp of some kind.

Care Of The Roller Chain

To prevent freezing of the roller chain due to rusting, remove and store submerged in fuel oil between seasons. Do not use regular oil for this purpose.

Parts






WITH 16 FT. UPPER AUGER
SEE ILLUSTRATION 39567AG

AC SYSTEMS INC. HUTCHINSON MN. 55350


NAME		DIMENSIONAL SPECS. W/13 FT. AUGER	
FIRST USED	MT24	DATE	12/19/05
REV.	A	DATE	02-06-14
		PART NUMBER	28875-24

288




MT24 ONLY
NO MOUNTS HERE

FOR MT24 ONLY, MOUNT ANGLES AT FRONT & REAR HOPPERS ONLY. INSTALL BOLTS WITH WASHERS UNDER THE BOLT HEAD AND NUTS. INSTALL SNUG ONLY SO THAT THE UNIT CAN FLEX. (DOUBLE NUT THE BOLTS.) THE ANGLES MAY BE WELDED TO THE TRUCK FRAME OR BOLTED DOWN. THIS HARDWARE IS NOT SUPPLIED.



MOUNTING KIT PN. 28978 CONTENTS

- 18092030 BOLT, 1/2-13NC. X 2 16
 - 18811400 FLAT WASHER 32
 - 18417400 HEX. NUT, 1/2-13NC 32
 - 28976 MOUNTING ANGLE 8
- FOR MT32 USE (2) COMPLETE KITS
(16) ANGLES ETC.



IMPORTANT

THE MOUNTING HARDWARE AS SHOWN IS INTENDED FOR FLAT BOTTOM TRAILERS ONLY. ANYTHING ELSE WILL REQUIRE SOME OTHER METHOD AS DEVISED BY THE USER.

ON TRAILERS WITH HIGH BEDS, SPECIAL CARE SHOULD BE TAKEN BECAUSE OF THE HIGH CENTER OF GRAVITY. ADDITIONAL TIE-DOWNS SHOULD BE USED, SUCH AS CHAIN BINDERS AND SLOWER SPEEDS ON THE ROAD SHOULD BE MAINTAINED.

AG SYSTEMS INC. HUTCHINSON MN. 55350

MOUNT TENDER, MT16 & MT24 AND MT32

NAME TRAILER MOUNTING ILLUSTRATION

FIRST USED MT16, MT24 & MT32 DATE 03/07/05

REV. DATE

PART NUMBER 39120AG

MT-24 MOUNTING ILLUSTRATION

INSTALLATION OF MOUNTING KIT #18384A

18384A-DOC
1-26-11
rev 11-12-13

TRUCK CHASSIS MOUNTED VERSION

FORMULA TO DETERMINE WT. PER AXLE.

$$\frac{\text{TOTAL LOAD X DIM "A"}}{\text{DIM "B" (WHL BASE)}} = \text{WT. ON FRONT AXLE}$$

EXAMPLE
 $\frac{52302 \text{ X } 31 \text{ (DIM A)}}{248 \text{ (DIM B)}} = 6538\# \text{ ON FRONT AXLE}$


LOAD WT. MINUS WT. ON FRONT AXLE = WT. ON REAR AXLES

EXAMPLE
 $52302 - 6538 = 45764\# \text{ ON REAR AXLES}$

NOTE
 INFO SHOWN TO BE USED AS A GUIDE ONLY. ACTUAL FIGURES MAY VARY DEPENDING ON TRUCK AXLES, WHEELBASE, CROSSMEMBER LOCATIONS, AND WEIGHT OF TRUCK (NOT INCLUDED) ETC.

STRUCK CAP. MT24 TENDER,
 771 CU.FT. X 62# (MATL) - 47802#
 FERT. WT. --- 47802#
 UNIT WT. ----- 4500#
 TOTAL WT. --- 52302#

DOES NOT INCLUDE WEIGHT OF TRUCK




AXLE SPACING AND WHEELBASE WILL VARY BY TRUCK MFG
 REF DIMENSIONS SHOWN ARE ONLY FOR EXAMPLE PURPOSES

FOR "FLAT BED" MOUNT
 SEE ILLUSTRATION
 39120AG

LADDER MOUNTING

MT16 WITH
13 FT. AUGER
AND MT24 ALL

28975ILL



REAR
MOUNTED LADDER

FRONT
MOUNTED LADDER

NOTES:

DECAL LISTING


(DECALS NOT TO SCALE)

REF	PART #	QTY	DESCRIPTION
1	11495B	1	WATCH FOR OVERHEAD CLEARANCE
2	12181A	1	CAUTION, BELT & DRIVE CHAIN
3	12182B	1	DANGER STAY CLEAR
4	12429A	1	CAUTION READ SERVICE MANUAL
5	28223	1	DRAIN OIL FROM TANK
6	28864	1	DANGER KEEP AWAY FROM HINGE
7	28954	1	CAUTION RAISING/LOWERING
8	29133	1	CAUTION DO NOT OPERATE
9	699107L	2	HEARTLAND AG SYSTEMS (MEDIUM)
10	28882A	1	CONTROL DRIVE LEVERS
11	54133	3	HEARTLAND AG SYSTEMS (X-LARGE)
12	276534	1	HYDRAULIC OIL LOGO
13	87268088	1	DANGER DO NOT ENTER FERT. TANK
14	USA	1	MADE IN USA
15	71615	1	MT24 (DITCH SIDE)
16	71616	1	MT24 (DRIVER SIDE)
17	699125	2	SAFETY DECAL (INCLUDED W/ SAFETY BAR KIT)
18	71672	1	CAUTION DISCHARGE (INCLUDED W/ CATWALK)


11495B




12181A



WATCH FOR
OVERHEAD
CLEARANCE
WHEN
OPERATING.



12182B



12429A




28223



28954



276534



71672



29133



699107L



71616



87268088




54133



699125




28882A




DECAL LAYOUT SHEET


(DECALS # 5 & 12 ARE LOCATED ON THE OIL TANK AND NOT SHOWN)




FRONT VIEW



REAR VIEW




SIDE VIEW (DRIVER)



SIDE VIEW (PASSENGER)

MT24 TENDER
 BODY AND FRAME
 ILLUSTRATION
 LEFT SIDE VIEW

MT24BDYLFT
 REV 10/31/19




ITEM PART NO.	DESCRIPTION	QTY
1 39563	BODY/FRAME, 3 COMPT STD (409 S.S. BOX, SEE NOTE)	1
1A 39563A	BODY/FRAME, 6 COMPT OPTION (409 S.S. BOX, SEE NOTE)	
1B 39563AS	BODY/FRAME, 6 COMPT OPTION (304 S.S. BOX, SEE NOTE)	
1C 39563AS-SR	BODY/FRAME, 7 COMPT OPTION (304 S.S. BOX, SPLIT REAR SEE NOTE)	
2 28964	BODY/FRAME, NON LWRG AGR OBS	6
3 18889A	GATE PLATE	6
4 28111A	LINKAGE	3
5 28612	GATE ARM MOUNT	3
6 28109	ARM STOP	6
7 54143A	VINYL HANDLE GRIP	7
8 18026826	BOLT, 3/8-16NC, X 1 1/2 SS	12
9 18476800	HEX. NUT, 3/8-16NC	SS 24
10 18026824	BOLT, 3/8-16NC, X 1 1/4 SS	6
11 18991200	FLAT WASHER, 3/8	SS 6
12 18476800	HEX. NUT, 3/8-16NC	SS 6
13 18026422	BOLT, 5/16-18NC, X 1.00"	SS 12
14 18987700	FLANGE NUT, 5/16-18NC	SS 12
15	HANDLE, (3) L.H. & (2) R.H. HANDLE, REAR GATE (1)	
ITEMS 14 & 15 ARE WELDED IN PLACE AT ASSEMBLY.		
FOR REPAIR PARTS ORDER-		
28112	SHAFT, 1" DIA. X 10 1/2"	
28113	COMMON ARM	
28114A	HANDLE, LEFT HAND	
28115A	HANDLE, RIGHT HAND	
303433	HANDLE, REAR (TEE TYPE)	
16 47005524	SAFETY STAND, AUGER SIDE	2
17 47005525	SAFETY STAND, HANDLE SIDE	2
18 18057446	BOLT, 1/2-13NC, X 4 ZC.	4
19 18417400	HEX. NUT, 1/2-13NC, ZC.	4
ITEMS 16 TO 19 ARE USED FOR STORAGE AND TRANSPORT ONLY. MAY BE RETURNED FOR CREDIT.		

NOTE:
 PRIOR TO 2016 THE 409 SS BOXES WERE ALL WHITE / AFTER 2016 THE 409 BOXES HAVE A WHITE UPPER/BLACK LOWER PORTION
 IN 2016 THE SS BOX WAS INTRODUCED, IT HAS A NATURAL FINISH (UNPAINTED) UPPER/BLACK LOWER PORTION
 PLEASE MENTION YEAR OF TENDER, TO RECEIVE CORRECTLY PAINTED ACCESSORIES

MT24 TENDER

BODY AND FRAME ILLUSTRATION RIGHT SIDE VIEW

MT24BDYRT
REV 12/28/20




MT24 TENDER

BODY AND FRAME ILLUSTRATION
(RIGHT SIDE) PARTS LIST

NOTE:
ALL HARDWARE IS
STAINLESS STEEL
EXCEPT WHERE NOTED

ITEM	PART NO.	DESCRIPTION	QTY.
1	39563	BODY/FRAME, LA, 3 COMPT STD (409 SS BOX SEE NOTE)	1
1A	39563A	BODY/FRAME, LA, 6 COMPT OPTION (409 SS BOX SEE NOTE)	1
1B	39563AS	BODY/FRAME, LA, 6 COMPT OPTION (304 SS BOX SEE NOTE)	1
1C	39563AS-SR	BODY/FRAME, LA, 7 COMPT OPTION (304 SS BOX, SPLIT REAR SEE NOTE)	1
2	28964	BODY/FRAME, "NON-LWRG-AUGER" BUMPER, "LOWERING AUGER"	1
3	39051	BRACE, 1/2-13NC. X 1 3/4	5
4	18470175	BOLT, 1/2-13NC. X 1 3/4	10
5	18824800	FLAT WASHER, 1/2	5
6	18567400	NYLOCK NUT, 1/2-13NC.	5
7	28124A	REF. "UPPER" LADDER KIT P.N. 28339 LADDER, UPPER	2
8	28810	MOUNTING BRACKET, LOWER	1
9	28809	MOUNT BRACKET, UPPER	2
10	18026822	BOLT, 3/8-16NC. X 1	4
10A	18706621	SCREW, MACHINE 3/8 X 3/4 TR SL	4
11	18991200	FLAT WASHER, 3/8	8
12	18566400	NYLOCK NUT, 3/8-16NC.	8
13	18026822	BOLT, 3/8-16NC. X 1	2
14	18991200	FLAT WASHER, 3/8	4
15	18566400	NYLOCK NUT, 3/8-16NC.	2
16	28974	ITEM 16 USED FOR SIDE OR FRONT MOUNT ONLY BRACE, LADDER	1
17	REF. "EXTENSION" LADDER KIT P.N. 28507		1
18	28125	EXTENSION LADDER	2
19	18027438	BOLT, 1/2-13NC. X 3	2
20	18824800	FLAT WASHER, 1/2	2
21	18567400	NYLOCK NUT, 1/2-13NC.	2
21	18026824	BOLT, 3/8-16NC. X 1 1/4	3
22	18991200	FLAT WASHER, 3/8	6
23	18566400	NYLOCK NUT, 3/8-16NC.	3
24	39032	BRACE, BUMPER	1
25	18026824	BOLT, 3/8-16NC. X 1 1/4	1
26	18991200	FLAT WASHER, 3/8	2
27	18566400	NYLOCK NUT, 3/8-16NC.	2
28	06648	HANDLE (LADDER)	2
29	18026822	BOLT, 3/8-16NC. X 1	4
30	18991200	FLAT WASHER, 3/8	8
31	18566400	NYLOCK NUT, 3/8-16NC.	4
32	28922A	VALVE BRACKET	1
33	18026822	BOLT, 3/8-16NC. X 1	4
34	18991200	FLAT WASHER, 3/8	8
35	18566400	NYLOCK NUT, 3/8-16NC.	4
36	28818	LIGHT BRACKET, REAR	2
37	18026422	BOLT, 5/16-18NC. X 1	4
38	18991100	FLAT WASHER, 5/16	8
39	18457500	NUT NYLOCK, 5/16-18 NC ZC	4
40	28163	LIGHT BRACKET, FRONT- L.H.	1
41	28164	LIGHT BRACKET, FRONT- R.H.	1

ITEM	PART NO.	DESCRIPTION	QTY.
42	18026422	BOLT, 5/16-18NC. X 1	8
43	18991100	FLAT WASHER, 5/16	16
44	18457500	NUT NYLOCK, 5/16-18 NC ZC	8
		FENDER KIT P.N. 28815A, 28815T	
45	28815	FENDER, LEFT HAND	1
45A	71724	FENDER, LEFT HAND (FRONT)	1
45B	71726	FENDER, LEFT HAND (REAR)	1
46	28816	FENDER, RIGHT HAND	1
46B	71723	FENDER, RIGHT HAND (REAR)	1
47	28787	FENDER SUPPORT	5
48	18470175	BOLT, 1/2-13NC. X 1 3/4	3
49	18824800	FLAT WASHER, 1/2	10
50	18567400	NYLOCK NUT, 1/2-13NC.	20
51	39060	FENDER EXTENSION, L.H.	6
		FENDER KIT INCLUDES ITEMS 36-44	1
		28340 LIGHT KIT IS INCLUDED WITH FENDER KITS	1



ITEM	PART NO.	DESCRIPTION	QTY.
52	28866	FOR LOWERING AUGER ONLY FOR NON-LWRG. AUGER USE (2) OF ITEM 52	1
53	18026824	BOLT, 3/8-16NC. X 1 1/4	24
54	18991200	FLAT WASHER, 3/8	48
55	18566400	NYLOCK NUT, 3/8-16NC.	24
56	REF. MUD FLAP KIT P.N. 33244		2
57	47006302	SPLASH GUARD	2
58	18056826	MOUNTING STRAP	8
59	18811200	FLAT WASHER, 3/8	16
60	18459200	NYLOCK NUT, 3/8-16NC.	8
61	38937	FRAME EXTENSION	1
62	18470175	BOLT, 1/2-13NC. X 1 3/4	4
63	18824800	FLAT WASHER, 1/2	8
64	18567400	NYLOCK NUT, 1/2-13NC.	4

ITEM	PART NO.	DESCRIPTION	QTY.
65	02550	OPTIONAL BUMPER FOR NON- LOWERING AUGER ONLY	1
66	28808	BUMPER WELDMENT	1
67	18026824	BOLT, 3/8-16NC. X 1 1/4	4
68	18991200	FLAT WASHER, 3/8	8
69	18987900	FLANGE NUT, 3/8-16NC.	4
70	18470175	BOLT, 1/2-13NC. X 1 3/4	6
71	18824800	FLAT WASHER, 1/2	12
72	18567400	NYLOCK NUT, 1/2-13NC.	6


ITEM	PART NO.	DESCRIPTION	QTY.
73	29928	OPTIONAL FOR UNITS WITHOUT FENDERS AND PASSENGER SIDE REAR CONTROLS MOUNT, CONTROL VALVE (Optional)	1
74	39144	SUPPORT, VALVE MOUNT (Optional)	2

OPTIONAL FOR UNITS WITH DRIVER SIDE REAR CONTROLS
MOUNT, CONTROL VALVE (Optional) 1
BRACE, VALVE MOUNT (Optional) 2

NOTE:
PRIOR TO 2016 THE 409 SS BOXES WERE ALL WHITE / AFTER 2016 THE 409 BOXES HAVE A WHITE UPPER/BLACK LOWER PORTION
IN 2016 THE SS BOX WAS INTRODUCED, IT HAS A NATURAL FINISH (UNPAINTED) UPPER/BLACK LOWER PORTION
PLEASE MENTION YEAR OF TENDER, TO RECEIVE CORRECTLY PAINTED ACCESSORIES

MT24 AUGER ILLUSTRATION

HORIZONTAL AND UPPER UNLOADER




WHEN CONVERTING FROM ITEM 48A TO ITEM 48, ITEM 73 CLAMP COLLAR (P/N: STA-1L104HD) IS REQUIRED FOR THE END OF THE AUGER SHAFT.

2022 & NEWER

(PRE 2019)
48A

(2019 & NEWER)

CYLINDER CHANGED FROM WELDED TO TIE-ROD STARTING S/N 1091 (AUGUST 2023)



(CONNECTION ASSEMBLY #47003700 REPLACES #39034 STARTING FALL 2019)
FOR REPLACEMENT ON UNITS THAT ORIGINALLY CAME WITH PART #39034, ORDER P/N: 72462 (CONTAINS P/N: 47003700R AND P/N: 71107)

MT24 AUGER PARTS LIST
HORIZONTAL AND UPPER UNLOAD AUGER

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	39124	HORIZONTAL AUGER	1	40	28958	UPPER UNLOAD AUGER	1
C	28948	AUGER TUBE, INCLUDES PARTS A & B	1		28804	AUGER TUBE, 16 FT. (DISCONTINUED)	N/A
D	18026824	AUGER TUBE SPLICE	1		28957	AUGER TUBE, 13 FT. (DISCONTINUED)	N/A
E	18991200	BOLT, 3/8-16NC. X 1 1/4	6	41	28957	AUGER TUBE, 17 FT. (DISCONTINUED)	1
F	18566400	FLAT WASHER, 3/8	6		28960A	SCREW, 16 FT. (DISCONTINUED)	N/A
2	28951	NYLOCK NUT, 3/8-16NC.	6		29027	SCREW, 13 FT. (DISCONTINUED)	N/A
3	47006519	SCREW	1		28959	SCREW, 17 FT. (DISCONTINUED)	N/A
4	28811	DRIVE KEY, 1/4 X 1/4 X 1 1/2	1	42	18901806	GREASE ZERK, 90 DEGREE	2
5	18026822	CLEAN-OUT DOOR	3	43	307623	PIVOT TUBE	1
6	18991200	BOLT, 3/8-16NC. X 1	18	44	28807A	THREADED ROD, 1-8NC. X 15 3/8	1
7	18566400	FLAT WASHER, 3/8	36	45	18852200	WASHER, FLAT 1" SAE ZC	4
8	10500	NYLOCK NUT, 3/8-16NC.	18	46	18439000	HEX. NUT, 1-8NC.	2
9	18026826	FLANGE BRG, 1" BORE	1	47	18449005	JAM NUT, 1-8NC.	2
10	18566400	BOLT, 3/8-16NC. X 1 1/2	2	48	47003537	AUGER GUIDE SHAFT (2019 & NEWER)	1
11	29921	NYLOCK NUT, 3/8-16NC.	2	48A	29028	SCREW GUIDE CABLE ASS'Y (PRE 2019)	1
12	18026824	MOTOR MOUNT PLATE	1			IS SHOWN FOR REFERENCE ONLY)-----	
13	18991200	BOLT, 3/8-16NC. X 1 1/4	4	49	28846A	CRADLE SUPPORT BRACE	1
14	18566400	FLAT WASHER, 3/8	8	50	18026824	BOLT, 3/8-16NC. X 1 1/4	3
15	18470175	NYLOCK NUT, 3/8-16NC.	4	51	18991200	FLAT WASHER, 3/8	3
16	18567400	BOLT, 1/2-13NC. X 1 3/4	2	52	18566400	NYLOCK NUT, 3/8-16NC.	3
17	10181	NYLOCK NUT, 1/2-13NC.	2	53	28835A	CRADLE SUPPORT	1
18	17701	SPROCKET, #50B18, 1" BORE	2	54	18026826	BOLT, 3/8-16NC. X 1 1/2	2
19	53159	COUPLING CHAIN, #50-2 X 17 LINKS	1	55	18991200	FLAT WASHER, 3/8	4
20	47003700	CONNECTOR, #50-2	1	56	18566400	NYLOCK NUT, 3/8-16NC.	2
21	---	TUBE ADAPTER	1	57	18026824	BOLT, 3/8-16NC. X 1 1/4	2
22	---	CONNECTION ASSEMBLY	1	58	18991200	FLAT WASHER, 3/8	4
23	18026822	BOLT, 3/8-16NC. X 1	8	59	18566400	NYLOCK NUT, 3/8-16NC.	2
24	18566400	NYLOCK NUT, 3/8-16NC.	8	60	18026824	BOLT, 3/8-16NC. X 1 1/4	4
25	39024	TUBE CLAMP	1	61	18991200	FLAT WASHER, 3/8	4
26	39020	TUBE CRADLE (HORIZONTAL)	1	62	18566400	NYLOCK NUT, 3/8-16NC.	4
27	39048	CRADLE SUPPORT (HORIZ. TUBE)	1	63	29862	TUBE CRADLE	1
28	18026826	BOLT, 3/8-16NC. X 1 1/2	4	64**	52056	FLANGE BRG. 1 1/4 BORE	1
29	18991200	FLAT WASHER, 3/8	8	65**	18026824	BOLT, 3/8-16NC. X 1 1/4	2
30	18566400	NYLOCK NUT, 3/8-16NC.	4	66	---	OMITTED	---
31	18026824	BOLT, 3/8-16NC. X 1 1/4	4	67**	18987900	FLANGE NUT, 3/8-16NC.	2
32	18991200	FLAT WASHER, 3/8	4	68	07132	HYDRAULIC CYLINDER, (3 1/2 X 8)	1
33	18566400	NYLOCK NUT, 3/8-16NC.	4	69	---	---	REPAIR PARTS ONLY
34	18470175	BOLT, 1/2-13NC. X 1 3/4	4	70	86632567	CYLINDER PIN,	2
35	18824800	FLAT WASHER, 1/2	8	71	18560826	COTTER PIN, 3/16 X 1 1/2	2
36	18567400	NYLOCK NUT, 1/2-13NC.	4	72	18852200	FLAT WASHER, 1" SAE	2
37	01078	STRETCH STRAP (BUNGEE)	3	73**	STA-1L104HD	CLAMP COLLAR, 1 1/4"	1

(* ITEMS 40 & 41 ARE INCLUDED IN THE UPPER UNLOAD AUGER ASSEMBLY)
(UPPER UNLOAD AUGER ASSEMBLY P/N: 29151 BREAKDOWN ON NEXT 2 PAGES)

ITEM 68 SWITCHED FROM A WELDED CYLINDER TO A TIE ROD (AUGUST 2023)
STARTING S/N: 1091. MAY NEED TO MODIFY, OR REPLACE GUIDE WELDMENT P/N: 39016
FOR ADDITIONAL CLEARANCE ON PREVIOUS MODEL YEARS WHEN REPLACING CYLINDER


16' UNLOAD AUGER TUBE ASSEMBLY

P/N: 29151

PART LISTING

(FOR MT16, MT24, & MT32)
BILL OF MATERIALS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	28958	16' AUGER WELDMENT	1
2	28960A	SCREW WELDMENT, RH	1
3	71251	FOUR BOLT FLANGE MOUNT BEARING	1
4	18997446	BOLT 1/2NC X 4 LG SS	4
5	71252	COMPRESSION SPRING (SS)	4
6	71250	BEARING COVER	1
7	18567400	NUT SS NYLOCK 1/2	4
8	18026822	BOLT, HEX HD 3/8 X 1 NC SS	5
9	18566400	NUT SS NYLOCK 3/8	4
10	STA-1L104HD	CLAMP COLLAR	1
11	71715	TAIL SHAFT WASHER	1
12	18881201	LOCKWASHER, 3/8 SS	1




16' UNLOAD AUGER TUBE ASSEMBLY

P/N: 29151

ILLUSTRATION


(FOR MT16, MT24, & MT32)
BILL OF MATERIALS

VIEW HAS BEEN ROTATED TO BETTER VIEW BEARING END



MT16 MT24 AND AUGER ILLUSTRATION
 MT32
 LOWER UNLOAD AUGER
 (DIRECT DRIVE)

MT16AGRLU
 03-24-10
 REV 03/04/24



3A
 ADDED FALL 2023
 BEGINNING
 MT24 S/N:1093
 MT16 S/N:1080

MT16, MT24 & MT32

AUGER PARTS LIST

LOWER UNLOAD AUGER

MT16AGRLULST
03-24-10
REV 04/22/24

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	308132	AUGER TUBE,	1	33	30708	FLANGE BRG. 1 1/4 BORE	1
2	29026	SCREW,	1	33A	18901807	GREASE ZERK 45', 1/4-28	1
2A	18026826	BOLT, 3/8-16 X 1 1/2 SS	1	34	18026826	BOLT, 3/8-16NC. X 1 1/2	2
2B	18476800	NUT, HEX 3/8-16 SS	2	35	18566400	NYLOCK NUT, 3/8-16NC.	2
3	29931	DRIVE PIN WELDMENT	1	36	31407	SPROCKET, #50B24, 1 1/4 BORE	1
3A	71910	AUGER DRIVE BUSHING	1	37	10183	SPROCKET, #50B24, 1" BORE	1
4	47006519	DRIVE KEY, 1/4 SQ. X 1 1/2	1	38	29941	COUPLING CHAIN, #50-2 X 23 LINKS	1
5★	50165	MACHINERY WASHER, 1 1/4 X 10 GA.	1	39	53159	CONNECTOR, #50-2	1
6	18026822	BOLT, 3/8-16NC. X 1	3	40	29921	MOTOR MOUNT PLATE	1
7	18476800	HEX. NUT, 3/8-16NC.	3	41	18991200	BOLT, 3/8-16NC. X 1 1/4	4
8	28704	COVER PLATE	1	42	18566400	FLAT WASHER, 3/8	8
9	18026824	BOLT, 3/8-16NC. X 1 1/4	4	43	18022026	NYLOCK NUT, 3/8-16NC.	4
10	18991200	FLAT WASHER, 3/8	8	44	18567400	BOLT, 1/2-13NC. X 1 1/2	2
11	18566400	NYLOCK NUT, 3/8-16NC.	4	45	39016	NYLOCK NUT, 1/2-13NC.	2
12	28918	CLEAN-OUT DOOR	1	46	18026824	AUGER GUIDE	1
13	29927	SHIELD, HYDRAULIC MOTOR	1	47	18991200	BOLT, 3/8-16NC. X 1 1/4	4
14	28828	END CAP	1	48	18566400	FLAT WASHER, 3/8	4
15	18026824	BOLT, 3/8-16NC. X 1 1/4	2	49	39047	NYLOCK NUT, 3/8-16NC.	4
16	18991200	FLAT WASHER, 3/8	4	50	18470175	CYLINDER ANCHOR	1
17	18566400	NYLOCK NUT, 3/8-16NC.	2	51	18824800	BOLT, 1/2-13NC. X 1 3/4	3
18	18026822	BOLT, 3/8-16NC. X 1	8	52	18567400	FLAT WASHER, 1/2	3
19	18991200	FLAT WASHER, 3/8	8	53	39254	NYLOCK NUT, 1/2-13NC.	3
20	18566400	NYLOCK NUT, 3/8-16NC.	8	54	92395	HYDRAULIC CYLINDER,	1
21	10500	FLANGE BRG. 1" BORE	1	54	92395	REPAIR CLEVIS ONLY	1
22	18026826	BOLT, 3/8-16NC. X 1 1/2	2	55	86632567	REPAIR CLEVIS ONLY (NOT SHOWN)	2
23	18566400	NYLOCK NUT, 3/8-16NC.	2	56	18560826	CYLINDER PIN,	2
24	39025	AUGER PIVOT WELDMENT	1	57	18852200	COTTER PIN, 3/16 X 1 1/2	2
25	18901805	GREASE ZERK, STRAIGHT	1	ITEMS	58, 59, AND 60	FLAT WASHER, 1" SAE	2
26	18026824	BOLT, 3/8-16NC. X 1 1/4	4	58	18470175	ITEMS 58, 59, AND 60 INSTALLED FOR SHIPPING ONLY	1
27	18991200	FLAT WASHER, 3/8	8	59	18824800	BOLT, 1/2-13NC. X 1 3/4	2
28	18566400	NYLOCK NUT, 3/8-16NC.	4	60	18567400	FLAT WASHER, 1/2	1
29	39028	PIVOT MOUNT	1			NYLOCK NUT, 1/2-13NC.	1
30	18026830	BOLT, 3/8-16NC. X 2	2	61	01078	BUNGEE CORD	1
31	18991200	FLAT WASHER, 3/8	4				
32	18566400	NYLOCK NUT, 3/8-16NC.	2				


ITEMS 54-56 ARE REPAIR PARTS ONLY

ITEM 3A - P/N: 71910 ADDED FALL 2023 (STARTING MT24 S/N: 1093 AND MT16 S/N: 1080)
CAN BE RETROFITTED ON PREVIOUS MODEL YEARS TO REDUCE AUGER RUNOUT

★ STARTING FALL 2023 QTY 1 - P/N: 50165 (10 GA) & QTY 1 - P/N: 50169 (14 GA) SHIPS LOOSE WITH MANUAL,
IN CASE P/N: 29026 REQUIRES HEIGHT ADJUSTMENT, AFTER BREAK IN PERIOD. THE MACHINE SHIPS STANDARD
FROM FACTORY WITH QTY 1 - P/N: 50165 (10 GA) WASHER INSTALLED.

MT16/MT24 TENDER
 BASIC HYDRAULIC SYSTEM FOR
 MT16/MT24 WITH REAR MOUNTED CONTROLS
 (COMPLETE HYDRAULIC PLUMBING KIT 29152)

29152
 10/26/21



PARTS LIST COMPLETE P.N. 29152
FOR REAR MOUNTED CONTROL VALVE

WARNING! FOR SAFETY, HYD CONTROLS MUST BE MOUNTED
A MINIMUM OF 7FT FROM THE AUGER FOLD !

ITEM	PART NO.	DESCRIPTION	QTY
		DELETE ITEMS 1 TO 8 WHEN USING "ENGINE DRIVE PACKAGE"	
1	38711	TANK, HYDRAULIC OIL (20 GAL.)	1
2	02153	DIPSTICK	1
3	02006	GATE VALVE, 1 1/4 NPT.	1
4	72368	HOSE BARB, 90° 1 1/4P X 1 1/4H	1
5	72175	OIL TANK PLUG 1/2" NPT	1
6	not included	HOSE, 1 1/4 I.D. X 80 (CUT LENGTH)	1
6A	not included	HOSE CLAMP, 1 1/2 inch	2
7	51933	HEX. PIPE NIPPLE,(5404-16-12)	1
8	01170	FILTER, COMPLETE	1
8A	11128	FILTER ELEMENT ONLY	
9	51682	TEE, 3/4 NPT(M) X 3/4 NPT(F)(2 PL)	1
10	51062	ELBOW, 45° 3/4 NPT(M) X 3/4 NPT(F)	2
11	53558	HOSE ASSY, 3/4" x 24" #12JICF X 3/4M PIPE	1
12	444001	ADAPTER, (6400-12)	4
13	51930	HYDRAULIC MOTOR, (104-1041-006)	2 (OR)
		W/30 HP.ENGINE DRIVE USE (1) OF ITEM 13 & (1) OF ITEM 33	
14	53601	HOSE ASSY, 3/4" x 36" #12JICM X #12JICFS 90°	3
15	53599	HOSE ASSY, 3/4" x 114" #12JICM X 3/4M PIPE	1
16	53598	HOSE ASSY., 3/4" x 34" #12JICM X 3/4M PIPE	1
17	53592	TUBE ASSY. HARDLINE 3/4 O.D. X 138 #12JICFS EA.END	3
		FOR THE MT24 MODEL ONLY, ADD ITEMS 17A AND 17B	
17A	51676	HEX. UNION, (2403-12-12)	3
17B	53606	TUBE ASSY. HARDLINE 3/4 O.D. X 96" #12JICFS EA.END	3
		FOR MT16 & MT24 CONTINUE AS SHOWN	
18	53600	HOSE ASSY., 3/4 x 36" #12JICFS X #12JICM	1
19	444007	ADAPTER,(6400-12-10)	3
20	444008	ADAPTER, (6400-8-10)	4
21	53602	HOSE ASSY., 1/2" x 60" #8JICFS X #8JICFS 90°	2
22	53528	HOSE ASSY., 1/2" x 72" #8JICFS X #8JICFS 90°	2
23	442020	ADAPTER, (2501-8-6)	2
24	28187	RESTRICTOR, (.062R) (5405-6-6R)	2
25	OMITTED	---	-
26	07132	SEE PG. 31&32 HYDRAULIC CYLINDER(LIFT CYL.)	
27	29091	SEE PG. 37 CONTROL VALVE (4 BANK)	1
27A	28882A	DECAL, CONTROL VALVE	1
27B	28904	STOP BRACKET, (VALVE LEVERS)	1
28	21243	PLUG, (6408-10)	1
29	OMITTED	---	
30	306338	PLUG, (6408-12)	1
31	343085A1	HOSE ASSY. 3/4" x 58" #12JICFS 90° EA. END	1
32	445001	ADAPTER, 90° (6801-12)	2
33	39165	HYD. MOTOR, (ENG. DRIVE UNITS ONLY) ref. item 13	1
		W/30 HP. ENGINE DRIVE USE (1) OF ITEM 13 & (1) OF ITEM 33	
34	53949	HOSE ASSY., 3/4 x 42", #12JICFS X #12JICFS 90°	1
35	39254	SEE PG. 33&34 HYDRAULIC CYL. (LWRG. AUGER)	
		SEE PG. 33&34 REPAIR CLEVIS	
		SEE PG. 33&34 CYL. REPAIR KIT	
36	2501-08-08	ELBOW 90° #8 MJIC X #8 MNPT	2
37	2406R-08-08-.062	ADAPTER, #8 MJIC X #8 FJIC	2


QTY. REQ'D. IS QTY. SHOWN ABOVE

*** 28973 HYDRAULIC HOSE KIT INCLUDES ITEMS 11,14,15,16,
18,21,22,31,AND 34

*** 28973A HYDRAULIC FITTING KIT INCLUDES ITEMS 7,9,10,12,
19,20,23,24,28,30,32,36 AND 37

MT16/MT24 TENDER
 BASIC HYDRAULIC SYSTEM FOR
 MT16/MT24 WITH REAR MOUNTED CONTROLS (DRIVER SIDE)
 (COMPLETE HYDRAULIC PLUMBING KIT 29153)

29153
 03/12/24




PARTS LIST COMPLETE P.N. 29153
FOR REAR MOUNTED CONTROL VALVE DRIVER SIDE

ITEM	PART NO.	DESCRIPTION	QTY
		DELETE ITEMS 1 TO 8 WHEN USING "ENGINE DRIVE PACKAGE"	
1	38711	TANK, HYDRAULIC OIL (20 GAL.)	1
2	02153	DIPSTICK	1
3	02006	GATE VALVE, 1 1/4 NPT.	1
4	72368	HOSE BARB, 90° 1 1/4P X 1 1/4H	1
5	72175	OIL TANK PLUG 1/2" NPT	1
6	not included	HOSE, 1 1/4 I.D. X 80 (CUT LENGTH)	1
6A	not included	HOSE CLAMP, 1 1/2 inch	2
7	51933	HEX. PIPE NIPPLE, (5404-16-12)	1
8	01170	FILTER, COMPLETE	1
8A	11128	FILTER ELEMENT ONLY	
9	51682	TEE, 3/4 NPT(M) X 3/4 NPT(F)(2 PL)	1
10	51062	ELBOW, 45° 3/4 NPT(M) X 3/4 NPT(F)	2
11	53558	HOSE ASSY, 3/4" x 24" #12JICF X 3/4M PIPE	1
12	444001	ADAPTER, (6400-12)	4
13	51930	HYDRAULIC MOTOR, (104-1041-006)	2 (OR)
		W/30 HP.ENGINE DRIVE USE (1) OF ITEM 13 & (1) OF ITEM 33	
14	53601	HOSE ASSY, 3/4" x 36" #12JICM X #12JICFS 90°	1
15	53599	HOSE ASSY, 3/4" x 114" #12JICM X 3/4M PIPE	1
16	53598	HOSE ASSY., 3/4" x 34" #12JICM X 3/4M PIPE	1
17	53592	TUBE ASSY. HARDLINE 3/4 O.D. X 138 #12JICFS EA.END	3
		FOR THE MT24 MODEL ONLY, ADD ITEMS 17A AND 17B	
17A	51676	HEX. UNION, (2403-12-12)	3
17B	53606	TUBE ASSY. HARDLINE 3/4 O.D. X 96" #12JICFS EA.END	3
		FOR MT16 & MT24 CONTINUE AS SHOWN	
18	72072	HOSE ASSY., 3/4 x 62" #12JICFS X #12JICM	1
19	444007	ADAPTER, (6400-12-10)	3
20	444008	ADAPTER, (6400-8-10)	4
21	53602	HOSE ASSY., 1/2" x 60" #8JICFS X #8JICFS 90°	2
22	53528	HOSE ASSY., 1/2" x 72" #8JICFS X #8JICFS 90°	2
23	442020	ADAPTER, (2501-8-6)	2
24	28187	RESTRICTOR, (.062R) (5405-6-6R)	2
25	OMITTED	----	-
26	07132	SEE PG. 31&32 HYDRAULIC CYLINDER(LIFT CYL.)	
27	29091	SEE PG. 37 CONTROL VALVE (4 BANK)	1
27A	28882A	DECAL, CONTROL VALVE	1
27B	28904	STOP BRACKET, (VALVE LEVERS)	1
28	21243	PLUG, (6408-10)	1
29	OMITTED	----	
30	306338	PLUG, (6408-12)	1
31	343085A1	HOSE ASSY. 3/4" x 58" #12JICFS 90° EA. END	1
32	445001	ADAPTER, 90° (6801-12)	2
33	39165	HYD. MOTOR, (ENG. DRIVE UNITS ONLY) ref. item 13	1
		W/30 HP. ENGINE DRIVE USE (1) OF ITEM 13 & (1) OF ITEM 33	
34	72073	HOSE ASSY., 3/4 x 56", #12JICFS X #12JICM	1
35	39254	SEE PG. 33&34 HYDRAULIC CYL. (LWRG. AUGER) SEE PG. 33&34 REPAIR CLEVIS SEE PG. 33&34 CYL. REPAIR KIT	
36	2501-08-08	ELBOW 90° #8 MJIC X #8 MNPT	2
37	2406R-08-08-.062	ADAPTER, #8 MJIC X #8 FJIC	2
38	72009	HYD. HOSE 3/4" X 56" #12 JICM X #12 JICFS 90°	1
39	72074	HYD. HOSE 3/4" X 62" #12 JICFS 45° X #12 JICM	1
		QTY. REQ'D. IS QTY. SHOWN ABOVE	
***	72008	HYDRAULIC HOSE KIT INCLUDES ITEMS 11, 14, 15, 16, 18, 21, 22, 31, 34, 38 & 39	
***	28973A	HYDRAULIC FITTING KIT INCLUDES ITEMS 7, 9, 10, 12, 19, 20, 23, 24, 28, 30, 32, 36 & 37	

VALVE - (4-BANK)

COMPLETE P/N: 29091





--- IN & OUT PORTS - SAE 12 (TOP)
 --- WORKING PORTS - SAE 10

- SECT #1 -- 4-WAY 3-POSITION DETENT (SERIES)
- SECT #2 -- 4-WAY 3-POSITION DETENT (SERIES)
- SECT #3 -- 4-WAY (TANDEM) -.053" RESRICTOR (WORK PORT)
- SECT #4 -- 4-WAY (TANDEM) -.053" RESRICTOR (WORK PORT)
 - W/ LOCKOUT FEATURE

REF.	PART NO.	QTY	DESCRIPTION
	98344	1	SEAL KIT (1-SPOOL & SECTION)
	98345	1	SEAL KIT (1-SPOOL)
	98346	1	SEAL KIT (1-SECTION)
	98347	1	SEAL KIT (RELIEF VALVE)
	98348	1	RELIEF VALVE COMPLETE -- 2750 PSI
	98349	1	HANDLE KIT - W/ BRACKETS W/ LINK & PIN
	98350	1	HANDLE ONLY
	98351	1	BRACKET ONLY
	98352	1	LINK KIT - W/ PINS
	98561	1	VALVE SECTION COMPLETE - SECT #3 & #4
	98898	1	CLEVIS ASSY (SPOOL) - SECT #1 & #2
	306743		SPRING - RELIEF (2750 PSI)
	06782047		OUTLET CASTING

MT29932PLBG
10/26/21

MT24 KOHLER ENGINE DRIVE
HYDRAULIC PACKAGE
WITH FRONT MOUNT CONTROL VALVE
COMPLETE P.N. 29932



MT24 KOHLER ENGINE DRIVE
HYDRAULIC PACKAGE PARTS LIST

MT29932LST

RV 10/26/21

WITH FRONT MOUNT CONTROL VALVE
COMPLETE P.N. 29932

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	CH750-0003	ENGINE, KOHLER, 30 HP.	1	29	444001	ADAPTER, #12 O-RING X #12 JIC	5
2	24-78611	MUFFLER KIT	1	30	444007	ADAPTER, #10 O-RING X #12 JIC	3
3	28991	MOUNT WELDMENT, ENGINE	1	31	444008	ADAPTER, #10 O-RING X #8 JIC	4
4	52295	ADAPTER, PUMP	1	32	21243	PLUG, #10 O-RING	1
5	52243	PUMP	1	33		OMITTED	
6	52245	COUPLER, 1.43" BORE	1	34	22431	CAP, #8 JIC	1
7	52294MOD	COUPLER, .62" BORE	1	35	53563	HOSE ASSEMBLY, (100R2) 3/4 X 54"	1
8	53536	SPIDER, COUPLER	1	36	51930	HYDRAULIC MOTOR	1
9	445001	ADAPTER, 90° #12 O-RING X #12 JIC	2	37	53583	HOSE ASSEMBLY, (100R2) 3/4 X 48"	1
10	4604-20-16	ADAPTER, #16 O-RING X 1 1/4 HOSE	1	38	51139	TEE, 3/4 NPT.	1
11	2575535	FUEL TANK, POLYETHYLENE	1	39	05347	ADAPTER, 3/4 NPT. X #12 JIC	2
12	CAP, W/TANK-SEE LOCAL HARDWARE STORE			40	53528	HOSE ASSEMBLY, (100R2) 1/2 X 70"	1
13	ELBOW, W/TANK, NO REPAIR			41	53602	HOSE ASSEMBLY, (100R2) 1/2 X 60"	1
14	53433	HOSE BARB, 1/4 NPT X 1/4 HOSE	1	42	53727	UNION, #12 JIC. X #8 JIC.	4
15	29135	FUEL LINE, 1/4 I.D. X 36"	1	43	53606	HYDRAULIC TUBE, 3/4 O.D. X 96"	4
16	200244	HOSE CLAMP,	4	44	51676	UNION, #12 JIC. X #12 JIC.(2403-12-12)	6
17	53431	FUEL FILTER, IN-LINE	1	45	53592	HYDRAULIC TUBE, 3/4 O.D. X 138"	4
18	38711	HYDRAULIC OIL TANK	1	46	53728	HOSE ASSEMBLY, (100R2) 1/2 X 56"	1
19	02153	DIPSTICK	1	47	53046	HOSE ASSEMBLY, (100R2) 1/2 X 48"	1
20	NOT USED			48	442020	ADAPTER, 90°	2
21	12003490	GATE VALVE, 1 1/4 NPT	1	49	28187	RESTRICTOR,	2
22	200250	ELBOW (RED) 90° 1 1/4P X 1 1/4H	1	50	OMITTED		
23	51933	HOSE BARB,	1	51	07132	HYDRAULIC CYLINDER	1
24	01170	HOSE, (100R3) 1 1/4 I.D. X 15 1/2"	1	52	53597	HOSE ASSEMBLY, (100R2) 3/4 X 76"	2
25	11128	HOSE CLAMP	2	53	53949	HOSE ASSEMBLY, (100R2) 3/4 X 58"	1
26	2404-12-12	NIPPLE, (5404-16-12)	1	54	29928	MOUNT, VALVE (W/O FENDERS ONLY)	1
27	53556	OIL FILTER (COMPLETE)	1	55	10183	SPROCKET, 50B24, 1" BORE	1
28	53601	FILTER ELEMENT	1	56	31407	SPROCKET, 50B24, 1 1/4 BORE	1
29	29091	ADAPTER, 3/4 NPT. X #12 JIC	2	57	39165	HYDRAULIC MOTOR	1
30	28882A	HYD. HOSE, 3/4 X 58"	2	58	343085A1	HOSE ASSEMBLY, (100R2) 3/4 X 58"	1
31	28904	HYD. HOSE, 3/4 X 36"	2	59	39254	HYDRAULIC CYLINDER	1
32		CONTROL VALVE	1	60	53602	HOSE ASSEMBLY, (100R2) 1/2 X 60"	2
33		DECAL, CONTROL VALVE	1	61	72175	OIL TANK PLUG 1/2" NPT	1
34		STOP BRACKET, VALVE HANDLES	1	62	2501-08-08	ELBOW 90°, #8 MJIC X #8 MNPT	2
35				63	2406R-08-08-.062	ADAPTER #8 MJIC X #8 FJIC	2

MT16 AND
MT24

ENGINE DRIVE PACKAGE COMPLETE

MT16E&TMNTLST
REV 04-21-15

FOR REAR VALVE MOUNT
30 HP ENGINE PKG # 33570

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	CH750-0003	ENGINE, KOHLER, 30 HP.	1	31	11128	FILTER ELEMENT ONLY	1
2	24-78611	MUFFLER PACKAGE	1	32	2404-12-12	ADAPTER, 3/4 M PIPE X #12JIC	1
3	18051628	BOLT, 3/8-16 X 1 3/4 GR 5	ZC 4	33	632144	HOSE ASSY., 3/4 X 144"	2
4	18811200	FLATWASHER, 3/8	ZC 8				
5	18457800	NUT, CENTERLOCK, 3/8-16	ZC 4	34	6506-12-12	ADAPTER, 3/4FM PIPE X #12JICFS	1
6	52295	ADAPTER, ENGINE TO PUMP	1	35	01353	BATTERY BOX, POLYETHYLENE	1
7	18054123	BOLT, 7/16-18 X 1 1/4	ZC 4	36	18706421	BOLT, 5/16-18NC. X 3/4	4
8	18891300	LOCKWASHER, 7/16	ZC 4	37	18991110	LOCK WASHER, 5/16	4
9	2-1711	DRIVE KEY, 3/8 SQ. X 2	1	38	18991100	FLAT WASHER, 5/16	4
10	52245	COUPLER HALF, 1.43 BORE, W/ 3/8 KEY	1	39	18987700	FLANGE NUT, 5/16-18NC.	4
11	52294MOD	COUPLER HALF, MOD .625 BORE, 5/32 KWY	1	40	148505	BATTERY CABLE, (POS) RED 48 INCH	1
12	53536	SPIDER COUPLER, HYTREL RBBR.	1	41	01351	BATTERY CABLE, (NEG) BLK. 38 INCH	1
13	52243	HYD. PUMP, 2-BOLT, W/KEY	1	42	47009519	J-BOLT, 5/16-18NC x 3 1/2	1
14	445001	ADAPTER, 90° (6801-12)	1	43	18496400	FLANGE NUT, 5/16	1
15	18056820	BOLT, 3/8-16 X 1	ZC 2	44	18406400	HEX. NUT, 5/16-18NC.	1
16	18811200	FLATWASHER, 3/8	ZC 2	45	1105172	HOLD-DOWN STRAP	1
16A	18891200	LOCKWASHER, 3/8	ZC 2	46	2575535	GASOLINE TANK (POLYETHYLENE)	1
17	4604-20-16	ADAPTER,	1	47	FILLER CAP, SEE LOCAL HARDWARE STORE		1
18	12003490	HOSE, 1 1/4 I.D. X 15 1/2	1	48	53433	HOSE BARB, (4244-4-4)	1
19	200256	HOSE CLAMP, FOR 1 1/4 HOSE	2	49	H175	FUEL LINE, HOSE 1/4 I.D. X 36"	1
20	72368	ELBOW/HOSEBARB, X 90 DEG., 1 1/4	1	50	53431	FUEL FILTER, IN-LINE	1
21	02006	GATE VALVE, 1 1/4 NPT.	1	51	200244	HOSE CLAMP, (7/16 - 1")	4
22	38711	HYDRAULIC OIL TANK (STEEL)	1	52	28991	FRAME, ENGINE & TANK MOUNT	1
23	02153	CAP/DIPSTICK	1	53	18057434	BOLT, 1/2-13NC. X 1 1/2	4
24	72175	OIL TANK PLUG 1/2" NPT	1	54	18811400	FLAT WASHER, 1/2	4
25	18056824	BOLT, 3/8-16NC. X 1 1/4	ZC 4	55	18891400	LOCK WASHER, 1/2	4
26	18811200	FLAT WASHER, 3/8	ZC 4	56	18417400	HEX. NUT, 1/2-13NC.	4
27	OMITTED			57	39165	HYDRAULIC MOTOR	1
28	18496800	FLANGENUT, 3/8-18NC.	ZC 4				
29	51933	HEX. PIPE NIPPLE, (5404-16-12)	1				
30	01170	FILTER COMPLETE	1				

MT16E&TRTRO
04-21-15

MT16 AND ENGINE DRIVE RETROFIT PACKAGE
MT24

FOR REAR VALVE MOUNT

KOHLER 30 HP ENGINE-PKG. #33570RET

WARNING! FOR SAFETY, HYD CONTROLS MUST BE MOUNTED A MINIMUM OF 7 FT FROM THE AUGER FOLD!

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	CH750-0003	ENGINE, KOHLER, 30 HP.	1	30	01170	FILTER COMPLETE	1
2	24-78611	MUFFLER PACKAGE	1	31	11128	FILTER ELEMENT ONLY	1
3	18051628	BOLT, 3/8-16 X 1 3/4 GR5	ZC 4	32	2404-16-12	ADAPTER, 3/4 M PIPE X #12JIC	1
4	18811200	FLATWASHER, 3/8	ZC 8	33	632144	HOSE ASSY., 3/4 X 144"	2
5	18457800	NUT, CENTERLOCK, 3/8-16	ZC 4	34	6506-12-12	ADAPTER, 3/4FM PIPE X #12JICFS	1
6	52295	ADAPTER, ENGINE TO PUMP	1	35	01353	BATTERY BOX, POLYETHYLENE	1
7	18054123	BOLT, 7/16-18 X 1 1/4	ZC 2	36	18706421	BOLT, 5/16-18NC. X 3/4	4
8	18811300	FLATWASHER, 7/16	ZC 2	37	18991110	LOCK WASHER, 5/16	4
9	2-1711	DRIVE KEY, 3/8 SQ. X 2	1	38	18991100	FLAT WASHER, 5/16	4
10	52245	COUPLER HALF, 1.43 BORE, 3/8 KEY	1	39	18987700	FLANGE NUT, 5/16-18NC.	4
11	52294MOD	COUPLER HALF, MOD. .625 BORE, 5/32 KEY	1	40	148505	BATTERY CABLE, (POS) RED 48 INCH	1
12	53536	SPIDER COUPLER, HYTREL RBBR.	1	41	01351	BATTERY CABLE, (NEG) BLK. 38 INCH	1
13	52243	HYD. PUMP, 2-BOLT, W/KEY	1	42	47009519	J-BOLT, 5/16-18NC.	1
14	445001	ADAPTER, 90° (6801-12)	1	43	18496400	FLANGE NUT, 5/16	1
15	18056820	BOLT, 3/8-16 X 1	ZC 2	44	18406400	HEX. NUT, 5/16-18NC.	1
16	18811200	FLATWASHER, 3/8	ZC 2	45	1105172	HOLD-DOWN STRAP	1
16A	18891200	LOCKWASHER, 3/8	ZC 2	46	2575535	GASOLINE TANK (POLYETHYLENE)	1
17		ADAPTER,	1	47		FILLER CAP, SEE LOCAL HARDWARE STORE	1
18		HOSE, 1 1/4 I.D. X 15 1/2"	1	48	53433	HOSE BARB, (4244-4-4)	1
19		HOSE CLAMP, FOR 1 1/4 HOSE	2	49	H175	FUEL LINE, HOSE, 1/4 I.D. X 36"	1
20		ELBOW/HOSEBARB, X 90 DEG., 1 1/4	1	50	53431	FUEL FILTER, IN-LINE	1
21		GATE VALVE, 1 1/4 NPT.	1	51	200244	HOSE CLAMP, (7/16 - 1")	4
22		HYDRAULIC OIL TANK (STEEL)	1	52	28991	FRAME, ENGINE & TANK MOUNT	1
23		CAP/DIPSTICK	1	53	18057434	BOLT, 1/2-13NC. X 1 1/2	4
24		OIL TANK PLUG 1/2" NPT	1	54	18811400	FLAT WASHER, 1/2	4
25	18056824	BOLT, 3/8-16NC. X 1 1/4	ZC 4	55	18891400	LOCK WASHER, 1/2	4
26	18811200	FLAT WASHER, 3/8	ZC 4	56	18417400	HEX. NUT, 1/2-13NC.	4
27	OMITTED			57	39165	HYDRAULIC MOTOR	4
28	18436800	HEX. NUT, 3/8-18NC.	ZC 4				1
29	51933	HEX. PIPE NIPPLE, (5404-16-12)	ZC 1				

REUSE EXISTING PARTS



51682 TEE, 3/4 PIPE, (2)F X (1)M
REF. ONLY, PART OF BASIC HYDRAULIC SYSTEM

MT24 TENDER HYDRAULIC SYSTEM FOR

MT24TMKPLBG
RV 03/03/23

TRUCK MOUNTED (WET KIT) WITH HYD CONTROLS MOUNTED ON DRIVER SIDE REAR
(WARNING ! FOR SAFE OPERATION, HYD CONTROLS MUST BE MOUNTED A MINIMUM OF 7FT AWAY FROM THE AUGER FOLD)
(*WET KIT* IS WHEN HYD PUMP AND TANK ARE ALREADY ON THE TRUCK SUPPLIED BY CUSTOMER)
(COMPLETE HYDRAULIC PLUMBING KIT MT24TMKKIT)

ITEM	PART NO	QTY	DESCRIPTION	ITEM	PART NO	QTY	DESCRIPTION
1	51930	2	HYDRAULIC MOTOR	8A	28187	2	RESTRICTOR (5405-06-06-062)
2	444001	3	ADAPTER, SAE/JIC	9	442020	2	ADAPTER 90° (2501-08-06)
3	28091	1	HYDRAULIC CONTROL VALVE	10	607132	2	HYD HOSE, 1/2" X 132, #BJICFS X #BJICFS 90°
3A	28882A	1	DECAL LEVERS	11	632144	3	HYD HOSE, 3/4" X 144, #12JICFS90° X #12JICM
3B	28904	1	STOP BRACKET, VALVE LEVERS	12	53601	1	HYD HOSE, 3/4" X 36, #12JICFS90° X #12JICM
4	444008	4	ADAPTER, SAE/JIC	13	53558	1	HYD HOSE, 3/4" X 24, #12JICM X 3/4" MNPT
5	21243	1	PLUG, (6408-10)	14	53598	2	HYD HOSE, 1/2" X 144, #BJICFS X #BJICFS 90°
6	444007	3	ADAPTER, (6400-12-10)	15	607144	2	HYD HOSE, 3/4" X 138, #12JICFSX80 X #12JICFS
7	07132	1	HYDRAULIC CYLINDER	16	53138	3	HYDRAULIC TUBE, 3/4" X 96" LONG #12FJIC EA END
7A	OMITTED	1	HYDRAULIC CYLINDER	17	53606	3	TUBE UNION (2403-12-12)
8	39254	1	REPAIR CLEVIS	18	51678	1	ELBOW CONNECTOR, 90° (6801-12)
9	92395	1	REPAIR SEAL KIT	19	445001	1	TEE, 1 INCH NPT
9B	98180	1	REPAIR SEAL KIT	20	72292	2	BUSHING, 1 NPT - 3/4 NPT
				21	72299	2	ELBOW 90°, #8 M/JIC X #8 MNPT
				22	2501-08-08	2	ADAPTER, #8 M/JIC X #8 F/JIC
				23	2408R-08-08-062	2	ADAPTER, #8 M/JIC X #8 F/JIC
				24			





MT24 TENDER HYDRAULIC SYSTEM FOR

MT24 WITH FRONT MOUNTED DRIVERS SIDE CONTROLS
(HYDRAULIC POWERPACK) (2023 AND BEYOND)
(COMPLETE HYDRAULIC PLUMBING KIT 29154-24)

FOR TRUCK MOUNT W/O OIL TANK PLEASE SEE PRINT MT24FRMTOL
ITEMS 30 THRU 38 ARE NOT REQUIRED

MT24FRMTWTANK
08/01/23


ALSO REQUIRED:
PART NUMBER QTY
70686 1
18057426 2
18891400 2
18851400 2
18417400 2





ITEM PART NO	QTY	DESCRIPTION
1 51830	2	HYDRAULIC MOTOR
2 ---	1	HYDRAULIC CONTROL VALVE
3 28081	1	DECAL, CONTROL VALVE
3A 28082A	1	PORT PLUG, O-RING 6408-10
3B 21243	1	HYDRAULIC CYLINDER
4 07132	1	HYDRAULIC CYLINDER
7A ---	1	HYDRAULIC CYLINDER
8 32254	1	REPAIR KIT
8A 92385	1	REPAIR KIT
9 28187	2	ADAPTER W. Ø82 ORIFICE
10 442020	2	ADAPTER, ELB 90° 2501-8-6
11 ---	3	ADAPTER, 6400-12-10
12 444007	3	ADAPTER, 6400-8-10
13 444008	2	ADAPTER, 6400-12
14 444001	2	ADAPTER, 6400-12
15 ---	1	HYD HOSE KIT CONSISTS OF ITEMS 16 THRU 19, ITEMS 23 AND ITEMS 25 THRU 27
16 47980060	2	HYD HOSE, 3/4 X 42, #12JICM X #12JICFS 90°
17 607060	2	HYD HOSE, 1/2 X 60 #12JICM X #12JICFS
18 607064	2	HYD HOSE, 1/2 X 64 #12JICM X #12JICFS 45°
19 632063	1	HYD HOSE, 3/4 X 63 #12JICM X #12JICFS ON ENDS
20 53592	6	HYDRAULIC TUBE, 3/4 X 138 #12JICFS ON ENDS
21 445001	4	TUBE UNION (2403-12-12)
22 445001	4	ELBOW CONNECTOR, 90° (6601-12)
23 610060	1	HYD HOSE, 3/4 X 60, #12JICFS 90° X #12JICM
24 53808	6	HYD TUBE, 3/4 X 96 LG #12JIC BOTH ENDS
25 610072	2	HYD HOSE, 1/2 X 72, #12JICM X #12JICFS 90°
26 610088	2	HYD HOSE, 1/2 X 65 #12JICFS X #12JICFS 90°
27 53949	2	HYD HOSE, 3/4 X 42, #12JICFS X #12JICFS 90°
28 2501-08-08	2	ELBOW 90°, #8 MCM X #8 MNPT
29 2408R-08-08-082	2	ADAPTER, #8 MCM X #8 FJIC
30 38711	1	DIRT, HYDRAULIC OIL (20 GAL)
31 02153	1	DIRT, HYDRAULIC OIL (20 GAL)
32 72398	1	GATE VALVE, 1 1/4 NPT
33 72398	1	HOSE BARB, 90° 1 1/4 X 1 1/4
34 72175	1	OIL TANK PLUG 1/2 NPT
35 ---	2	HOSE, 1 1/4 ID
35A NOT INCLUDED	2	HOSE CLAMP, 1 1/2
36 51933	1	HEX PIPE NIPPLE (5404-16-12)
37 01170	1	FILTER, COMPLETE
37A 11128	1	FILTER ELEMENT ONLY
38 2605-12-12	1	RUN TEE
39 632036	1	HYD HOSE, 3/4 X 36 #12 JICFS X #12JICFS 90°
40 304-C-12	1	CAP

FRONT MOUNT CONTROL DECAL LOCATION ADJUSTMENT

FOR UNITS WITH FRONT MOUNT CONTROLS,
THE DECALS NEED TO BE APPLIED AS SHOWN
ON THIS PAGE INSTEAD OF AS SHOWN ON PG. 27




DETAIL A
SCALE 1:10



MT24 TENDER
HYDRAULIC SYSTEM FOR

MT24 WITH FRONT MOUNTED DRIVERS SIDE CONTROLS
(HYD SOURCE TO BE SPECIFIED BY CUSTOMER)


ITEM	PART NO	QTY	DESCRIPTION	ITEM PART NO	QTY	DESCRIPTION
1	51930	2	HYDRAULIC MOTOR	14	444001	2 ADAPTER, 6400-12
2	538138	2	HYDRAULIC HOSE X 138"	15	53573	1 RIN TEE
3	28081	1	HYDRAULIC CONTROL VALVE	47960060		HYD HOSE KIT, CONSISTS OF ITEMS 16 THRU 19, ITEMS 23 AND ITEMS 25 THRU 27
3A	28804A	1	EXCAVATOR CONTROL VALVE	18	53942	2 HYD HOSE 3/4 X 42 #12JICFS 90°
3B	28804	1	STOP BRACKET, VEE LEVERS	17	607060	2 HYD HOSE 1/2 X 80 #12JICFS 90°
4	21243	1	PORT PLUG, O-RING 6408-10	18	607064	2 HYD HOSE 1/2 X 84 #12JICFS 90°
7	07132	1	HYDRAULIC CYLINDER	19	632063	1 HYD HOSE, 3/4 X 63 #12JICFS 45°
7A	39254	1	HYDRAULIC CYLINDER	20	53692	6 HYDRAULIC TUBE, 3/4 X 138 #12JICFS ON ENDS
8	92355	1	REPAIR KIT	21	445001	6 TUBE UNION (2403-12-12)
8A	26187	2	REPAIR SEAL KIT	22	445001	4 ELBOW CONNECTOR, 90° (6501-12)
9	442020	2	ADAPTER, W .062 ORIFICE	23	610060	1 HYD HOSE, 3/4 X 60, #12JICFS 90° X #12JICFS
10	---	2	ADAPTER, ELB 90° 2501-8-6	24	53608	6 HYD TUBE, 3/4 X 96 LG #12JIC BOTH ENDS
11	---	2	ADAPTER, ELB 90° 2501-8-6	25	610072	2 HYD HOSE, 1/2 X 48, #12JICFS X #12JICFS 90°
12	444007	3	ADAPTER, 6400-12-10	26	53949	2 HYD HOSE, 3/4 X 42, #12JICFS X #12JICFS 90°
13	444006	4	ADAPTER, 6400-8-10	28	2501-08-08	2 ELBOW 90°, #8 MISC X #8 MNPT
				29	2408-08-08-082	2 ADAPTER, #8 MISC X #8 FJIC



ALSO REQUIRED:

PART NUMBER	QTY	DESCRIPTION
70666	1	STIFFENER, STRUT
18057428	2	BOLT HK CAP GR.5 1/2 X 1 1/2 NC ZC
18851400	2	WASHER 1/2 LOCK ZC
18417400	2	NUT HK 1/2 NC ZC

FOR TRUCK MOUNT, ITEM 15 IS NOT NEEDED
ONE OF ITEM 2 NEEDS TO BE SHORTENED TO 29" LG (ITEM 2A)



MT16 AND MT24 ENGINE DRIVE PACKAGE COMPLETE


MT1624ENPKGLST
12-1-20

FOR REAR VALVE MOUNT
38 HP ENGINE PKG # 33577

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	ECH980-3001	ENGINE, KOHLER, 38 HP.	1	32	72280	CLOSE NIPPLE, 1" NPT	1
1A	62-376-02	ENG MT CONTROLS (INCLUDED W ENGINE)		33	21372	GATE VALVE, 1" NPT	1
2	6278614	MUFFLER STARTER SIDE 38 HP	1	34	51933	HEX. PIPE NIPPLE, (5404-16-12)	1
3	18051628	BOLT, 3/8-16 X 1 3/4 GR 5	ZC 4	35	01170	FILTER, COMPLETE WITH ELEMENT	1
4	18811200	FLATWASHER, 3/8	ZC 8	35A	11128	FILTER ELEMENT ONLY	1
5	18457800	NUT, CENTERLOCK, 3/8-16	ZC 4	36	2501-12-12	ELBOW 90°, 3/4 M PIPE X #12JIC	1
6	52295	ADAPTER, ENGINE TO PUMP	1	37	H176	FUEL LINE HOSE, 3/16 ID X 20" LONG	1
7	18054123	BOLT, 7/16-18 X 1 1/4	ZC 4	38	6506-12-12	ADAPTER, 3/4FM PIPE X #12JICFS	1
8	18891300	LOCKWASHER, 7/16	ZC 4	39	18056824	BOLT, HEX HD 3/8-16NC X 1 1/4 ZC	4
9	H175	FUEL LINE, HOSE 1/4 I.D. X 36"	ZC 4	40	18811200	FLATWASHER, 3/8	8
10	2-1711	DRIVE KEY, 3/8 SQ. X 2	1	41	18891200	LOCKWASHER, 3/8	4
11	52245	COUPLER HALF, 1.43 BORE, W/ 3/8 KEY	1	42	18436800	NUT, HEX 3/8-16NC ZC	4
12	52294MOD	COUPLER HALF, MOD .625 BORE, 5/32 KWY	1	43	47015917	ENGINE SKID WELDMENT	1
13	53536	SPIDER COUPLER, HYTREL RBBR.	1	44	47005963	BATTERY RETAINER STRAP	1
14	52243	HYD. PUMP, 2-BOLT, W/KEY	1	45	148505	BATTERY CABLE, (POS) RED 20 INCH	1
15	445001	ADAPTER, 90° (6801-12)	1	46	01351	BATTERY CABLE, (NEG) BLK. 38 INCH	1
16A	632144	HOSE ASSY.(REAR CONTROL VALVE UNITS ONLY)	2	47	18056830	BOLT, 3/8-16 NC X 2 LONG ZC	2
OR				48	18498800	FLANGENUT, 3/8-16 NC ZC	2
16B	53138	HOSE ASSY.(FRONT CONTROL VALVE UNITS ONLY)	2	49	730-2382	HOLD DOWN J-BOLT (NAPA 730-2382)	2
17	304-C-6	HOSE CAP, JIC #6	1	50	18457650	LOCKNUT 1/2-13 NYLOCK ZC	2
18	53431	FUEL FILTER, IN-LINE	1	51	FLO71021AE	GASOLINE TANK (POLYETHYLENE) 8 GAL replacement	1
19	609020	HOSE, CRANKCASE DRAIN 3/8" X 20"	1	52	200244	HOSE CLAMP, (7/16 - 1")	4
20	18056822	BOLT, 3/8 X 1 GR5	ZC 2	53	H175	FUEL LINE HOSE, 1/4 ID X 4" LONG	1
21	18891200	LOCKWASHER, 3/8	ZC 2	54	18057434	BOLT, HEX 1/2-13NC x 1 1/2 GR5	4
22	18811200	FLATWASHER,	ZC 2	55	18811400	FLATWASHER, 1/2" ZC	4
23	4601-20-16	ADAPTER, ELBOW 90° HOSE TO O-RING	1	56	18891400	LOCKWASHER, 1/2" ZC	4
24	200256	HOSE CLAMP, FOR 1 1/4 HOSE	2	57	18417400	HEX NUT, 1/2-13NC ZC	4
25	12003490	HOSE, 1 1/4 I.D. X 30 INCHES LONG	1	58	2517602	WIRING HARNESS FOR 38HP ENGINE	1
26	72368	HOSEBARB, 90° 1 1/4 NPT X 1 1/4 HS	1	59	2509932-M	IGNITION SWITCH 38 HP	1
27	02006	GATE VALVE, 1 1/4 NPT.	1	60	ST290110	THROTTLE CONTROL ASSY FOR 37HP	1
28	38711	HYDRAULIC OIL TANK (STEEL)	1	61	18025715	BOLT, HEX HEAD #10-24 X 3/4 SS	2
29	72175	OIL TANK PLUG 1/2" NPT	1	62	18987800	FLANGENUT, #10-24 SS	2
30	02153	CAP/DIPSTICK	1	63	-	-	-
31	72306	STREET ELBOW, 90° 1" NPT	1	64	-	-	-
ALSO INCLUDED BUT NOT SHOWN							
6217628	JUMPER WIRE HARNESS 38 HP	1	65	47070533	OPTIONAL FENDER MOUNT KIT (contains items 65-67)	1	1
			66	70533	IGNITION SWITCH FENDER MT BRKT	2	2
			67	18057424	BOLT, HEX HD 1/2-13 X 1 1/4 ZP	2	2
				18497400	FLANGENUT, 1/2-13 ZP	2	2

MT24ENGMT
03-12-13
rev 09/29/22

DEUTZ 46.2 HP POWERPAK
FRONT ENGINE MOUNT ILLUSTRATION
MT24/MT32 KIT PART NUMBER 48300331
(INCLUDES ALL ITEMS SHOWN ON THIS PRINT)
(RH FRONT SIDE VIEW MT24 or MT32)



DEUTZ 46.2 HP POWERPACK

MT24ENGMTLST
03-12-13
rev 09/29/22

PARTS LIST

FRONT ENGINE MOUNT FOR MT24 OR MT32
(MT24/MT32 KIT PART NUMBER 48300331)

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	D2011LO3i	ENGINE, DEUTZ DIESEL 46.2 HP	1	37	73653	BUSHING, 1 1/4 X 3/4 NPT	1
1A	D2011B	OPTIONAL GLOW PLUG KIT	1	38	2404-12-12	ADAPTER, 3/4P X #12JIC	1
2*		SNUBBERS AND WASHERS (WITH ENGINE PKG.)		39	2501-20-20	90° ELBOW, 1 1/4P X #20JIC	1
3	H175 (BULK)	FUEL SUCTION LINE 12"	1	40	72471	BUSHING, 2 X 1 1/2 NPT	1
4*	001CT30-186-01	KP10 IN LINE FUEL FILTER	1	41	72390	CLOSE NIPPLE, 1 1/2 NPT	1
5		FUEL RETURN LINE, (WITH ENGINE PKG. (32"))	6	42	51497	GATE VALVE, 1 1/2 NPT	1
6	200244	HOSE CLAMP, 7/16" - 1.00"	1	43	4501-24-24	HOSE BARB ADAPTER, 1.5P X 1.5 HOSE	1
7	H175 (BULK)	FUEL LINE, HOSE- X 36"	1	44	200258	HOSE CLAMP, 1 9/16" - 2 1/2"	2
8	18057446	BOLT, 1/2-13NC. X 4	4	45	12003501	SUCTION HOSE, 1 1/2 X 54"	1
9	18457650	NUT, CTR. LOCK, 1/2-13NC. ZC	8	46	18057426	BOLT, 1/2-13 X 1 1/2 ZC	4
10	1713610	COUPLING, PUMP	1	47	18811400	FLATWASHER, 1/2 ZC	4
11	MT32PUMP	HYDRAULIC PUMP, DUAL PRESSURE PORTS	1	48	18891400	LOCKWASHER, 1/2 ZC	4
12	(FORCE AM. # P315B193BEAB1766NAB171)		1	49	18417400	NUT, 1/2-13 NC ZC	4
13	18056822	BOLT, 3/8-16NC. X 1	2	50	01353	BATTERY BOX WITH LID (PLASTIC)	1
14	18891200	LOCKWASHER, 3/8	2	51	148505	BATTERY CABLE, POS. X 48"	1
15*	5310	ADAPTER, #12 O-RING X #12JIC	2	52	01351	BATTERY CABLE NEG. X 38"	1
16*	RC16905	EXHAUST PIPE (DEUTZ)	1	53	18706421	BOLT, 5/16-18 X 3/4 SS	4
17*	50963	RAIN CAP, 2" TUBE (DEUTZ)	1	54	18991100	FLATWASHER, 5/16 SS	8
18	4601-24	MUFFLER CLAMP, 2 1/4 DIA.	2	55	18991110	LOCKWASHER, 5/16 SS	4
19	48300314	ADAPTER, O-RING X 1 1/2 HOSE	1	56	18987700	NUT, 5/16-18 SS	4
20	72220	FUEL TANK, STEEL (14 gal capacity)	1	57	48300317	POWER PACK FRAME WELDT	1
21	60002	DRAIN PLUG, 3/4 NPT.	1	58	18057424	BOLT, 1/2-13 X 1 1/4 GR5	4
22	71761	FILL CAP, PRE-VENT, 2" NPT	1	59	18851400	FLATWASHER, 1/2 USS ZC	4
23	48300323	WIRE LOCK CLEVIS PIN 3/8 X 2	1	60	18891400	LOCKWASHER, 1/2 ZC	4
24	4501-4-4	SUCTION TUBE WELDMENT	1	61	18417400	NUT, 1/2-13 NC ZC	4
25	OMITTED	HOSE BARB 90° 1/4 NPT X 1/4	2	62*	H001379	PRECLEANER, (DEUTZ)	1
26	18057426	BOLT, 1/2-13NC. X 1 1/4	4	63	18057424	BOLT, 1/2-13 X 1 1/4 GR5	2
27	18811400	FLATWASHER, 1/2	4	64	47005720	GAUGE CLUSTER BRACKET	1
28	18891400	LOCKWASHER, 1/2	4	65	18891400	LOCKWASHER, 1/2 ZC	2
29	18417400	NUT, HEX. 1/2-13	4	66	18417400	NUT, 1/2-13 NC ZC	2
30	48300310	58 GALLON OIL TANK (46 gallons operating capacity)	1	67	18495700	FLANGENUT, 1/4-20 ZC	4
31	48300330	DIPSTICK	1	68	N100395	RUBBER ISOLATOR MOUNT	3
32	72220	DRAIN PLUG, 3/4NPT	1	69	18055716	BOLT, 1/4-20 UNC X 1/2 LG ZC	1
33	20239	OIL FILTER HEAD, 1 1/4 NPT	1	70	18891000	LOCKWASHER, 1/4 ZC	1
34	SE25	OIL FILTER ELEMENT ONLY	1	71	4309	SEPARATOR CONVERSION BASE	1
35	72330	CLOSE NIPPLE, 1 1/4 NPT	1	72	3123	FILTER ELEMENT (NAPA 3123)	1
36	72342	PIPE TEE, 1 1/4 NPT	1	73	200810	REDUCER, 1/2NPT-1/4 NPT	2
				74	4244-4-4	HOSEBARB, 1/4 NPT X 1/4 HOSE	2
				75	18056422	BOLT, HEX, 5/16-18 X 1 ZP	3
				76	18891110	LOCKWASHER, 5/16 ZP	3
				77	18457600	NUT, 5/16-18 ZP	3

* INDICATES PARTS SUPPLIED WITH THE DEUTZ ENGINE

(ALSO INCLUDED BUT NOT SHOWN 48309999 DIESEL EMISSION TAG)

DEUTZ CONTROL PANEL



**New Mechanical Panel (Engines Plus)
Part #9990648**

Repair Parts:


- 300646 Key Switch
- 300647 Replacement Key (Stamped 250)
- 300651 Hourmeter
- 300649 Temperature Gauge
- 300648 Oil Gauge
- 300650 Tachometer
- 300601 Rubber Mtg. Isolator Kit
- 300652 Isolator only

DEUTZ 74.2 HP ENGINE SKID


ILLUSTRATION

PART #: 48300385
2021 AND BEYOND

BILL OF MATERIAL - SHEETS 46A & 47A
ENGINE SKID DETAIL - SHEET 48A
CONTROL PANEL DETAIL - SHEET 49A
FUEL TANK DETAIL - SHEET 50A
OIL TANK DETAIL - SHEET 51A



EXPLODED VIEW



NORMAL VIEW

DEUTZ 74.2 HP ENGINE SKID

BILL OF MATERIAL - PART #: 48300385

BOM Table			
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	48300310	58 GALLON OIL TANK	1
2	71638	28 GALLON FUEL TANK, T4	1
3	01353	BATTERY BOX W/ LID	1
4	MT900TAPUMP	HYDRAULIC PUMP	1
5	48300330	DIP STICK	1
6	18057426	BOLT, HX CAP 1/2-13 X 1 1/2 LG	8
7	18891400	WASHER, 1/2 LOCK ZC	8
8	18417400	NUT, HX 1/2 NC ZC	4
9	18811400	WASHER, FLAT 1/2 ZC	8
10	18706421	BOLT, HX CAP 5/16-18 X 3/4 LG SS	3
11	18991100	WASHER, FLAT 5/16 SS	6
12	18991110	WASHER, LOCK 5/16 SS	3
13	18475240	BOLT HX CAP 1/2-13 X 1 1/4 LG SS	4
14	18824800	WASHER FLAT 1/2 SS	8
15	18567400	NUT SS NYLOCK 1/2	4
16	18457650	NUT CTR LOCK 1/2 ZP ZC	4
17	SE25	OIL FILTER ELEMENT 10 MIL	1
18	20239	OIL FILTER HEAD 1 1/4 NPT	1
19	72330	CLOSE NIPPLE 1 1/4" NPT	1
20	72355	1 1/4 STREET ELBOW	2
21	72342	PIPE TEE 1 1/4 NPT	1
22	72390	CLOSE NIPPLE 1 1/2	1
23	51497	GATE VALVE 1 1/2 NPT	1
24	4501-24-24	1 1/2 HOSE ADAPTER	1
25	02006	1 1/4" GATE VALVE	1
26	18987700	NUT 5/16 SERR FLG	3
27	6408-20	#20 O-RING PLUG	1

BOM Table			
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
28	2404-16-20	ADAPTER 1 1/4 NPT M X #16 JIC M	2
29	2404-12-20	ADAPTER 1 1/4 MNPT X #12 MJIC	1
30	6801-12-16	ELBOW 90 DEG #12 MJIC X #16 MORB	2
31	4601-24-20	BEADED HOSE TO ORING ELBOW 90	1
32	72220	DRAIN PLUG 3/4 NPT	1
33	1044762	2" X 1 1/2" EXTERNALLY MOUNTED STRAINER W/ BYPASS	1
34	71021	ENGINE SKID, DEUTZ T4	1
35	71024	CONTROL BOX WELDT	1
36	AGRICOVER CONTROL	AGRICOVER CONTROL (INCLUDED WITH TARP)	1
37	18566400	NUT SS NYLOCK 3/8	2
38	18176450	BOLT, CARRIAGE, 3/8-16 X 1	2
39	303264	CONTROL BOX	1
40	47995366	DEUTZ ENGINE	1
41	18058313	BOLT GR8 7/8-9 X 2 1/2 LG ZC YELLOW	6
42	18458454	NUT NYLOCK GR 8 7/8-9 ZC YELLOW	6
43	71103	19" HOSE WITH FITTINGS	1
44	2024-20-16	20 NPTM-16 JIC elbow	1
45	18026422	BOLT CAP SS 5/16 X 1	2
46	71627	DIE SPRING, 1 X 1.5, BLUE	2
47	18057438	BOLT, 1/2-13 X 3 GR5 ZP	2
48	18057428	BOLT HX CAP 1/2-13 X 1 3/4 ZC	2

NOTES:

1. THE AGRICOVER CONTROL IS INCLUDED WITH THE ROLL TARP KIT
2. THE 303264 CONTROL BOX IS INCLUDED WITH ENGINE

ITEMS ALSO INCLUDED BUT NOT SHOWN




PART NUMBER	DESCRIPTION	QTY
FBA12684100	FUEL LINE CLIPS	8
FBA12683100	HOSE LINE CLAMPS	2
12003501	SUCTION HOSE	1
71092	2 GA BATTERY CABLE 48" RED	1
71093	2 GA BATTERY CABLE 38" BLACK	1
31-7237	GROUP 27 BATTERY	1
4050	HYDRAULIC OIL	56
H178	1/2 FUEL LINE	6'
H177	3/8 FUEL LINE	7'
43082316	SUCTION HOSE CLAMPS	2

OIL DRAIN KIT AND 8' HARNESS EXTENSION ARE INCLUDED WITH POWER UNIT.

DEUTZ 74.2 HP ENGINE SKID ENGINE SKID DETAIL




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
3	01353	BATTERY BOX W/ LID	1
4	MT900TAPUMP	HYDRAULIC PUMP	1
6	18057426	BOLT, HX CAP 1/2-13 X 1 1/2 LG	4
7	18891400	WASHER, 1/2 LOCK ZC	4
9	18811400	WASHER, FLAT 1/2 ZC	4
10	18706421	BOLT, HX CAP 5/16-18 X 3/4 LG SS	3
11	18991100	WASHER, FLAT 5/16 SS	6
12	18991110	WASHER, LOCK 5/16 SS	3
16	18457650	NUT CTR LOCK 1/2 ZP ZC	4
26	18987700	NUT 5/16 SERR FLG	3
27	6408-20	#20 O-RING PLUG	1
30	6801-12-16	ELBOW 90 DEG #12 MJIC X #16 MORB	2
31	4601-24-20	BEADED HOSE TO ORING ELBOW 90	1
34	71021	ENGINE SKID, DEUTZ T4	1
40	47995366	DEUTZ ENGINE	1
41	18058313	BOLT GR8 7/8-9 X 2 1/2 LG ZC YELLOW	6
42	18458454	NUT NYLOCK GR 8 7/8-9 ZC YELLOW	6
46	71627	DIE SPRING, 1 X 1.5, BLUE	2
47	18057438	BOLT, 1/2-13 X 3 GR5 ZP	2
48	18057428	BOLT HX CAP 1/2-13 X 1 3/4 ZC	2

ASSEMBLY NOTE:
71627 DIE SPRINGS LOCATED ON FRONT MOUNTS
TIGHTEN TO COMPRESSED LENGTH OF 1.125"



DEUTZ 74.2 HP ENGINE SKID CONTROL PANEL DETAIL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
13	18475240	BOLT HX CAP 1/2-13 X 1 1/4 LG SS	4
14	18824800	WASHER FLAT 1/2 SS	8
15	18567400	NUT SS NYLOCK 1/2	4
35	71024	CONTROL BOX WELDT	1
36	AGRICOVER CONTROL	AGRICOVER CONTROL (INCLUDED WITH TARP)	1
37	18566400	NUT SS NYLOCK 3/8	2
38	18176450	BOLT, CARRIAGE, 3/8-16 X 1	2
39	303264	CONTROL BOX	1




DEUTZ 74.2 HP ENGINE SKID FUEL TANK DETAIL

14 GALLON
PART NUMBER: 71718
(PRIOR TO FALL 2023)

(MT900TA UP TO S/N 1119)
(VPA1000 UP TO S/N 1015)


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	71082	FUEL TANK 14 GALLON, T4	1
2	18475240	BOLT HX CAP 1/2-13 X 1 1/4 LG SS	4
3	18824800	WASHER FLAT 1/2 SS	8
4	18567400	NUT SS NYLOCK 1/2	4
5	1091809	FLUID LEVEL SIGHT GLASS	1
6	72220	DRAIN PLUG 3/4 NPT	1
7	71088	ADAPTER ELBOW, 1/2 HOSE, 1/2 NPT MALE	1
8	71089	ADAPTER ELBOW, 3/8 HOSE, 3/8 NPT MALE	1
9	71631	FILLER PIPE WITH BAFFLE	1
10	60002	CAP PREVENT CASTING AND FILL CAP	1
11	71761	WIRE LOCK CLEVIS PIN W/ LOOP 3/8 DIA 2 LG	1



28 GALLON
PART NUMBER: 71638
(FALL 2023 AND BEYOND)


(MT900TA S/N 1120 AND BEYOND)
(VPA1000 S/N 1016 AND BEYOND)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	71633	FUEL TANK 28 GALLON, T4	1
2	71631	FILLER PIPE WITH BAFFLE	1
3	1091809	FLUID LEVEL SIGHT GLASS	2
4	72220	DRAIN PLUG 3/4 NPT	1
5	71088	ADAPTER ELBOW, 1/2 HOSE, 1/2 NPT MALE	1
6	71089	ADAPTER ELBOW, 3/8 HOSE, 3/8 NPT MALE	1
7	71639	FUEL LEVEL GAUGE	1
8	18475240	BOLT HX CAP 1/2-13 X 1 1/4 LG SS	4
9	18567400	NUT SS NYLOCK 1/2	4
10	18824800	WASHER FLAT 1/2 SS	8
11	60002	CAP PREVENT CASTING AND FILL CAP	1
12	71761	WIRE LOCK CLEVIS PIN W/ LOOP 3/8 DIA 2 LG	1




NOTE: APPLY THREAD SEALANT TO ALL THREADED FITTINGS

DEUTZ 74.2 HP ENGINE SKID OIL TANK DETAIL



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
2	48300310	58 GALLON OIL TANK	1
5	48300330	DIP STICK	1
6	18057426	BOLT, HX CAP 1/2-13 X 1 1/2 LG	4
7	18891400	WASHER, 1/2 LOCK ZC	4
8	18417400	NUT, HX 1/2 NC ZC	4
9	18811400	WASHER, FLAT 1/2 ZC	4
17	SE25	OIL FILTER ELEMENT 10 MIL	1
18	20239	OIL FILTER HEAD 1 1/4 NPT	1
19	72330	CLOSE NIPPLE 1 1/4" NPT	1
20	72355	1 1/4 STREET ELBOW	2
21	72342	PIPE TEE 1 1/4 NPT	1
22	72390	CLOSE NIPPLE 1 1/2	1
23	51497	GATE VALVE 1 1/2 NPT	1
24	4501-24-24	1 1/2 HOSE ADAPTER	1
25	02006	1 1/4" GATE VALVE	1
28	2404-16-20	ADAPTER 1 1/4 NPT M X #16 JIC M	2
29	2404-12-20	ADAPTER 1 1/4 MNPT X #12 MJIC	1
32	72220	DRAIN PLUG 3/4 NPT	1
33	1044762	2" X 1 1/2" EXTERNALLY MOUNTED STRAINER W/ BYPASS	1
43	71103	19" HOSE WITH FITTINGS	1
44	2024-20-16	20 NPTM-16 JIC ELBOW	1
45	18026422	BOLT CAP SS 5/16 X 1	2

V20VALVE
08/15/16



IN & OUT PORTS - SAE 12 (TOP)
WORKING PORTS - SAE 10

VALVE ASS'Y V20-10048

ITEM	QTY	PARTNUMBER	DESCRIPTION
1	1	20-10-04	3 POS. 4WAY SPRING CTR. (#10 ORB) SECTION 1
2	2	20-10-DF4	VALVE SECT.W DBL ACTING SPOOL 3 WAY DETENT
3	1	20-10-L04	3 POS 4-WAY LOCKOUT
4	1	20-12-SF	SPLIT FLOW INLET, #12 ORB WITHOUT R/V (SEC 4)
5	1	20-LC-12	LEFT COVER, TOP/SIDE PORTS, #12 ORB W/O R/V
6	1	20-RC-12-E-MY	RIGHT COVER, OUTLET, PB OPTION, #12 ORB

REPLACEMENT PARTS AND SEAL KITS

7	2	WH-30	MAIN RELIEF VALVE, PRE SET @ 3000 PSI (USED IN LEFT COVER AND SPLIT FLOW INLET)
8	4	K-20-VH-B	COMPLETE HANDLE KIT (INCLUDES LINKS & PINS)
9	5	K-6027	COMPLETE SECTION SEAL KIT


MT24 TENDER STD. HYDRAULIC SYSTEM

FOR DEUTZ 46.2 HP OR 74 HP ENGINE DRIVE
(ENGINE DRIVE IN FRONT WITH CONTROL VALVE PASS. SIDE REAR)
(COMPLETE HYDRAULIC PLUMBING KIT MT24DED)

MT24DTZPLB6
REV 03/03/23

ITEM	PART NO	QTY	DESCRIPTION	ITEM	PART NO	QTY	DESCRIPTION
1	51930	2	HYDRAULIC MOTOR	14	2404-20-20	1	ADAPTER, PIPE X JIC
2	444001	5	ADAPTER, SAE/JIC (6400-12)	15	2403-20	1	ADAPTER, UNION-JIC
3*	V20-10048	1	HYDRAULIC CONTROL VALVE	16	6321-20	1	HYD HOSE, 3/4 X 120, #12JICFS EA, END
4	444008	4	ADAPTER, SAE/JIC	17	6321-20	1	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JIC
5	445001	4	ELBOW (6801-12)	18	6321-44	2	HYD HOSE, 3/4 X 144, #12JICFS90° X #12JIC
6	444007	2	ADAPTER (6400-12-10)	19	6322-10	1	HYD HOSE, 1/4 X 210, #20JICFS EA, END
7	07132	1	HYDRAULIC CYLINDER	20	6321-22	6	HYD HOSE, 1/4 X 120, #20JICFS EA, END
7A				19A	6321-22	6	HYDRAULIC TUBE, 3/4 X .38 #12JICFS EA, END
8	39254	1	HYDRAULIC CYLINDER	21	51876	2	TUBE UNION, (2403-12-12)
9	92395	1	REPAIR CLEVIS	22	53800	2	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JIC
10	98180	2	REPAIR SEAL KIT	23	632036	3	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JIC
11	28187	2	ADAPTER, W/.062 ORIFICE	24	53942	1	HYD HOSE, 3/4 X 42, #12JICFS90° X #12JIC
12	442020	2	ADAPTER, 90°	25	53602	2	HYD HOSE, 1/2 X 60, #8JICFS X #8JICFS 90°
13	73653	3	BUSHING, 3/4 X 1 1/4	26	53528	2	HYD HOSE, 1/2 X 72, #8JICFS X #8JICFS 90°
14	2404-12-12	3	ADAPTER, PIPE X JIC	27	343085A1	1	HYD HOSE, 3/4 X 60, #12JICFS90 EA, END
15	72330	2	CLOSE NIPPLE, 1 1/4NPT	28	21243	2	PORT PLUG, #10JIC, O-RING (6408-10)
16	72342	2	TEE, 1 1/4 NPT	29	47005791	1	MUFFLER CLAMP, 2 INCH
17				30	47005791	1	MOUNT ANGLE, FITS 2 INCH CLAMP
18				31	18056822	2	BOLT, HEX 3/8-16 NC X 1.00 LONG ZC
19				32	18496800	2	FLANGENUT, 3/8-16 NC
20				33	2501-08-08	2	ELBOW 90° #8 MJIC X #8 MNPT
21				34	2406R-08-08-.062	2	ADAPTER #8 MJIC X #8 FJIC

**WARNING! FOR SAFE OPERATION HYD CONTROLS MUST BE MOUNTED A MINIMUM OF 7 FT FROM THE AUGER FOLD!



TEE MOUNTING INSTRUCTIONS (SEE RH REAR OF TENDER DETAIL) LOCATE AND CLAMP ANGLE (ITEM 30) IN POSITION AS SHOWN, ALLOWING ROOM FOR FENDER MOUNTING IF NEEDED, THEN MATCH DRILL TWO 7/16 DIA HOLES 3 1/4 INCHES APART AND BOLT ON ANGLE (ITEM 30) TO HOLD 1 1/4 NPT TEES (ITEM 13) IN PLACE USING MUFFLER CLAMP ASSEMBLY (ITEM 29). POSITION TEES AS SHOWN, THEN TIGHTEN CLAMP DOWN. THEN CONNECT ALL PLUMBING TO TEES PER DIAGRAM ABOVE.

MT24 TENDER HYDRAULIC SYSTEM FOR


RETROFIT DIRECT DRIVE TO DEUTZ 46.2HP ENG DRIVE
(COMPLETE HYDRAULIC PLUMBING KIT MT24RETRO)
(ENGINE DRIVE IN FRONT W CONTROL VALVE PASS. SIDE REAR)
WARNING! FOR SAFE OPERATION HYD CONTROLS MUST BE MOUNTED A
MINIMUM OF 7 FT. FROM THE AUGER FOLD!

SOME ITEMS MAY BE REUSED FROM THE EXISTING
MT24 HYDRAULIC SYSTEM. REFER TO ILLUSTRATION
29152 IN THE MT24 MANUAL.
THE ITEM NUMBERS AND QUANTITIES IN THE BOXES
CORRESPOND WITH THOSE ON ILLUSTRATION # 29152.
REUSE THESE ITEMS.

ITEM	QTY	PART NO	DESCRIPTION
13	2	51930	HYDRAULIC MOTOR
12	4	444001	ADAPTER, SAE/JIC (6400-12)
1	1	V20-10048	HYDRAULIC CONTROL VALVE
4	4	444008	ADAPTER, SAE/JIC
5	4	444001	ADAPTER, SAE/JIC (6400-12)
6	4	444007	ADAPTER, SAE/JIC
7	1	07132	HYDRAULIC CYLINDER
7A	1	39254	HYDRAULIC CYLINDER
8	1	92385	REPAIR CLEVIS
8A	2	98180	REPAIR SEAL KIT
9	2	442020	ADAPTER, 90° (2501-08-06)
10	2	73653	BUSHING, 3/4 X 1 1/4
11	3	2404-12-12	ADAPTER, PIPE X JIC
12	3	72330	CLOSE NIPPLE, 1/4NPT
13	2	72342	TEE, 1 1/4 NPT

ITEM	QTY	PART NO	DESCRIPTION
14	1	2404-20-20	ADAPTER, PIPE X JIC
15	1	2403-20	ADAPTER, UNION-JIC
16	1	632120	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JICM
17	1	53601	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JICM
18	2	632144	HYD HOSE, 3/4 X 144, #12JICFS90° X #12JICM
19	1	632120	HYD HOSE, 1 1/4 X 210, #20JICFS EA, END
20	1	632122	HYD HOSE, 1 1/4 X 120, #20JICFS EA, END
21	1	53602	HYD HOSE, 1 1/4 X 120, #20JICFS EA, END
22	1	53600	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JICM
23	1	632036	HYD HOSE, 3/4 X 42, #12JICFS90° X #12JICM
24	1	53942	HYD HOSE, 3/4 X 60, #8JICFS X #8JICFS 90°
25	1	53602	HYD HOSE, 1/2 X 72, #8JICFS X #8JICFS 90°
26	1	53528	HYD HOSE, 3/4 X 60, #12JIFXS90 EA, END
27	1	343085A1	PORT PLUG, #10JIC, O-RING
28	2	21243	MUFFLER CLAMP, 2 INCH
29	1	47005791	MOUNT ANGLE, FTS 2 INCH CLAMP
30	1	47005761	BOLT, HEX 3/8-16 NC X 1.00 LONG ZC
31	2	18056822	FLANGENUT, 3/8-16 NC
32	2	18496800	HYD HOSE, 3/8-16 NC
33	2	2501-08-08	HYD HOSE, 3/8-16 NC
34	2	2406R-08-08-062	HYD HOSE, 3/8-16 NC

VALVE (ENLARGED VIEW)
(2) PORTS WILL NEED
TO BE PLUGGED
WITH ITEM 28




SEE ENGINE MOUNT ILLUSTRATION
FOR DEUTZ 46.2 HP POWERPACK
ILLUSTRATION # MT24ENGMT

PRESSURE PORTS
ON HYDRAULIC
MOTOR

RETURN TEE
ON OIL TANK

TEE MOUNTING INSTRUCTIONS (SEE RH REAR OF TENDER DETAIL)
LOCATE AND CLAMP ANGLE (ITEM 30) IN POSITION AS SHOWN, ALLOWING ROOM FOR FENDER MOUNTING IF NEEDED, THEN
MATCH DRILL TWO 7/16 DIA HOLES 3 1/4 INCHES APART AND BOLT ON ANGLE (ITEM 30) TO HOLD 1 1/4 NPT TEES
(ITEM 13) IN PLACE USING MUFFLER CLAMP ASSEMBLY (ITEM 29). POSITION TEES AS SHOWN, THEN TIGHTEN CLAMP DOWN.
THEN CONNECT ALL PLUMBING TO TEES PER DIAGRAM ABOVE.



MT24 TENDER HYDRAULIC SYSTEM FOR


MT24DTZPLBG2
REV 03/03/23

WARNING 1 FOR OPERATOR SAFETY HYD CONTROLS MUST BE MOUNTED AT A MINIMUM OF 7 FT AWAY FROM AUGER FOLD

(COMPLETE HYDRAULIC PLUMBING KIT MT24DED2)

ITEM	PART NO	QTY	DESCRIPTION	ITEM	PART NO	QTY	DESCRIPTION
1	51930	2	HYDRAULIC MOTOR	16	632120	1	HYD HOSE, 3/4 X 120, #12JICFS EA, END
2	444001	1	ADAPTER, SAE/JIC (6400-12)	17	53601	1	HYD HOSE, 3/4 X 36, #12JICFS90° X #12JICM
3	V20-10048	1	HYDRAULIC CONTROL VALVE	18	632144	5	HYD HOSE, 3/4 X 144, #12JICFS90° X #12JICM
4	444006	4	ADAPTER, SAE/JIC (6400-12)	19	632332	1	HYD HOSE, 1/2 X 132, #8JICFS X #8JICFS 90°
5	444001	4	ADAPTER, SAE/JIC (6400-12)	20	53592	3	HYDRAULIC TUBE, 3/4 X 138 #12JICFS EA, END
6	444007	2	ADAPTER, SAE/JIC (6400-12-10)	21	51676	3	TUBE UNION (2403-12-12)
7	07132	1	HYDRAULIC CYLINDER	22	445001	3	ELBOW CONNECTER, 90° (6801-12)
7A	-	-	-	23	53138	3	HYD HOSE, 3/4 X 138, #12JICFS90° X #12JICFS
8	39254	1	HYDRAULIC CYLINDER	24	53606	3	HYD TUBE X 96" LONG #12JICFS BOTH ENDS
9	92395	1	REPAIR CLEVIS	25	607132	2	HYD HOSE, 1/2 X 132, #8JICFS X #8JICFS 90°
9A	28187	2	REPAIR SEAL KIT	26	607144	2	HYD HOSE, 1/2 X 144, #8JICFS X #8JICFS 90°
10	442020	2	ADAPTER, W/062 ORIFICE	27	343085A1	2	PORT PLUG, #10JIC, O-RING (6408-10)
11	73653	3	BUSHING, 3/4 X 1 1/4	28	21243	2	MUFFLER CLAMP 2 INCH
12	2404-12-12	3	ADAPTER, PIPE X JIC	29	47005791	1	MOUNT ANGLE, FITS 2 INCH CLAMP
13	72330	3	CLOSE NIPPLE, 1 1/4NPT	30	47005761	1	BOLT, HEX 3/8-16 NC X 1.00 LONG ZC
14	2404-20-20	2	TEE, 1 1/4 NPT	31	18056822	2	FLANGENUT, 3/8-16 NC
15	2501-12-12	1	ADAPTER, PIPE X JIC	32	18496800	2	ELBOW 90° #8 MJIC X #8 MNPT
				33	2501-08-08	2	ADAPTER #8 MJIC X #8 FJIC
				34	2406R-08-08--062	2	ADAPTER #8 MJIC X #8 FJIC


VALVE (ENLARGED)
(2) PORTS WILL NEED
TO BE PLUGGED



SEE ENGINE MOUNT ILLUSTRATION FOR DEUTZ 46.2 HP POWERPACK ILLUSTRATION # MT24ENGMT


RETURN TEE ON OIL TANK

PRESSURE PORTS ON HYDRAULIC MOTOR




TEE MOUNTING INSTRUCTIONS (SEE RH REAR OF TENDER DETAIL)
LOCATE AND CLAMP ANGLE (ITEM 30) IN POSITION AS SHOWN, ALLOWING ROOM FOR FENDER MOUNTING IF NEEDED, THEN MATCH DRILL TWO 7/16 DIA HOLES 3 1/4 INCHES APART AND BOLT ON ANGLE (ITEM 30) TO HOLD 1 1/4 NPT TEES (ITEM 13) IN PLACE USING MUFFLER CLAMP ASSEMBLY (ITEM 29). POSITION TEES AS SHOWN, THEN TIGHTEN CLAMP DOWN. THEN CONNECT ALL PLUMBING TO TEES PER DIAGRAM ABOVE.

MT24 TENDER
HYDRAULIC SYSTEM FOR
MT24 WITH FRONT MOUNTED DRIVERS SIDE CONTROLS
(USING A DEUTZ ENGINE DRIVE PACKAGE MOUNTED IN FRONT OF BOX)
P/N: 40248003




ATTENTION !
SEE ENLARGED VIEW OF
VALVE CONNECTIONS
FOR FITTING & ASSY



ALSO REQUIRED:

PART NUMBER	QTY	DESCRIPTION
18057426	1	SCREW STRUT
18851400	2	BOLT HK CAP GR 5 1/2 X 1 1/2 NC ZC
18851400	2	WASHER 1/2 LOCK ZC
18851400	2	WASHER 1/2 SAE ZC
18417400	2	NUT HK 1/2 NC ZC




ITEM	PART NO	DESCRIPTION
1	51630	HYDRAULIC MOTOR
2	120-10048	HYDRAULIC CONTROL VALVE
3	28862A	DECAL, CONTROL VALVE
4	21243	PORT PLUG, O-RING 6408-10
5	51876	TUBE UNION (2403-12-12)
6	53562	HYDRAULIC TUBE, 3/4 X 136 #12JICFS ON ENDS
7	07132	HYDRAULIC CYLINDER
7A		
8	39254	HYDRAULIC CYLINDER
9	52395	REPAIR SEAL KIT
10	98180	ADAPTER, 85° ORIFICE (5405-8-8R)
11	444020	ADAPTER, ELB 90° 2501-8-B
12	72330	CLOSE NIPPLE, 1 1/4" NPT
13		ADAPTER, 8400-12-10
14	444008	ADAPTER, 8400-8-10
15	444001	ADAPTER, 8400-12
16	72542	PIPE TEE, 1 1/4" X 1/2" X 1/2"
17	607080	HYD HOSE, 3/4 X 42, #12JICFS X #12JICFS 90°
18	607084	HYD HOSE, 1/2 X 60, #12JICFS X #12JICFS 90°
19	52293	HYD HOSE, 1/2 X 64, #12JICFS X #12JICFS 90°
20	6500-12	HYD HOSE, 3/4 X 68, #12JICFS X #12JICFS 90°
21	53138	SWIVEL ELBOW 90°, 6500-12
22	445001	HYD HOSE, 3/4 X 136, #12JICFS X #12JICFS 90°
23	510080	ELBOW CONNECTOR, 90° (6801-12)
24	610072	HYD HOSE, 3/4 X 60, #12JICFS X #12JICFS 90°
25	610072	HYD HOSE, 1/2 X 72, #12JICFS X #12JICFS 90°
26	610049	HYD HOSE, 1/2 X 68, #12JICFS X #12JICFS 90°
27	53049	HYD HOSE, 3/4 X 42, #12JICFS X #12JICFS 90°
28	2404-20-20	ADAPTER, 1 1/4" PIPE TO #20 MJIC
29	832122	HYD HOSE, 1 1/4" X 120, #20MJICFS BOTH ENDS
30	2501-08-08	ELBOW 90° #8 MJIC X #8 MNPT
31	2408-08-08-082	ADAPTER #8 MJIC X #8 FJIC

HYD HOSE KIT, CONSISTS OF ITEMS 16-19, 21, 23, 25-27 & 29 (P/N: 47990070)

TENDER BOX EXTENSIONS
(24 TON) UP TO 2021
THREE COMPARTMENT
AND SIX COMPARTMENT

TDRX24T
 02/11/20



STANDARD EXTENSION MATERIAL IS 409 S.S. (PAINTED WHITE)
 UPGRADE TO UNPAINTED 304 S.S. SIMPLY BY ADDING AN "S"

THREE COMPARTMENT EXTENSIONS


409 S.S. ITEM PART NO.	304 S.S. PART NO.	DESCRIPTION	PKG. COMPLETE (3 COMP.)	QTY
1	44440002	END PANEL		2
2	47019078	SIDE PANEL, L.H.		2
3	47009128	SIDE PANEL, R.H.		2
4	47019128	CROSS PANEL (3 COMPARTMENT)		1
5	47009079	CENTER PANEL, L.H.		1
6	47019405	CENTER PANEL, R.H.		1
7	47019080	JOINT ANGLE, L.H.		4
8	47029080	JOINT ANGLE, R.H.		4
9	47019081	CORNER ANGLE		4
10	47019130	CORNER CAP	WITH OUT TOP COVER WITH FLIP-TOP	2
11	18706621	BOLT, TRUSS HD.	3/8"-16NC. X 3/4"	S.S. 118
12	18496800	FLANGE NUT,	3/8"-16NC.	Z.P. 118

SIX COMPARTMENT EXTENSIONS

409 S.S. ITEM PART NO.	304 S.S. PART NO.	DESCRIPTION	PKG. COMPLETE (6 COMP.)	QTY
1	44440000	END PANEL		2
2	47019078	SIDE PANEL, L.H.		2
3	47009128	SIDE PANEL, R.H.		2
4	47019128	CROSS PANEL (6 COMPARTMENT)		5
5	47009079	CENTER PANEL, L.H.		1
6	47019405	CENTER PANEL, R.H.		1
7	47019080	JOINT ANGLE, L.H.		7
8	47029080	JOINT ANGLE, R.H.		7
9	47019081	CORNER ANGLE		4
10	47019130	CORNER CAP	WITH OUT TOP COVER WITH FLIP-TOP	2
11	18706621	BOLT, TRUSS HD.	3/8"-16NC. X 3/4"	S.S. 168
12	18496800	FLANGE NUT,	3/8"-16NC.	Z.P. 168

MT24 EXTENSION PART LAYOUT

(2021 & NEWER)



MT24 EXTENSION PARTS LIST (2021 AND NEWER)

ITEM #	DESCRIPTION	MATERIAL	PART #	3 COMPARTMENT			6 COMPARTMENT			
				P/N: 71280 (409 MATERIAL)		P/N: 71115 (304 MATERIAL)		P/N: 71277 (409 MATERIAL)		P/N: 71080 (304 MATERIAL)
				QTY	QTY	QTY	QTY	QTY	QTY	
1	EXT. PANEL (END)	304	71056	-	2	-	-	-	2	
		409	71253	2	-	2	-	-	-	
2	EXT. PANEL (DRIVER REAR)	304	71061	-	1	-	-	-	1	
		409	71258	1	-	1	-	-	-	
3	EXT. PANEL (PASSENGER FRONT)	304	71063	-	1	-	-	-	1	
		409	71260	1	-	1	-	-	-	
4	EXT. PANEL (DRIVER FRONT)	304	71065	-	1	-	-	-	1	
		409	71262	1	-	1	-	-	-	
5	EXT. PANEL (PASSENGER REAR)	304	71067	-	1	-	-	-	1	
		409	71264	1	-	1	-	-	-	
6	EXT. PANEL (PASSENGER CENTER)	304	71069	-	1	-	-	-	1	
		409	71266	1	-	1	-	-	-	
7	EXT. PANEL (DIVIDER SECTION)	304	71071	-	-	-	-	-	3	
		409	71268	-	-	-	-	3	-	
8	EXT. PANEL (MIDDLE SECTION)	304	71073	-	2	-	-	-	2	
		409	71270	2	-	2	-	-	-	
9	EXT. PANEL (DRIVER CENTER)	304	71075	-	1	-	-	-	1	
		409	71272	1	-	1	-	-	-	
10	CORNER LOCK	304	71077	-	8	-	-	-	14	
		409	71274	8	-	14	-	-	-	
11	JOINT LOCK #1	304	71078	-	2	-	-	-	2	
		409	71275	2	-	2	-	-	-	
12	JOINT LOCK #2	304	71079	-	2	-	-	-	2	
		409	71276	2	-	2	-	-	-	
13	EXTERIOR CORNER	304	71104	-	4	-	-	-	4	
		409	71278	4	-	4	-	-	-	
14	NUT SER FLG 3/8	SS	18987900	76	76	100	100	100	100	
15	BOLT , HX CAP 3/8-16 X 3/4 LG	SS	18026820	60	60	84	84	84	84	
16	SCREW SLOTTED TRUSS HEAD 3/8 X 3/4 LG	SS	18706621	16	16	16	16	16	16	

CATWALK ILLUSTRATION


MT32 CONFIGURATION - P/N:40329215



MT24 CONFIGURATION - P/N:40249215



MT16 CONFIGURATION - P/N:40169215



(SEE CTWKINST FOR
GENERAL
MOUNTING
INSTRUCTIONS ON
THE FOLLOWING
PAGE.)

MT16 P/N:40169215 QTY. 1
MT24 P/N:40249215 QTY. 1
MT32 P/N:40329215 QTY. 1



INCLUDED, BUT NOT SHOWN
1 - P/N: 71672 CAUTION DISCHARGE
AUGER STICKER

FRONT OF
TENDER

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	47019278	CATWALK EXTENDED	1
2	47019215	CATWALK	-
3	70933	CATWALK EXTENDED (SPECIAL)	1
4	47019209	CATWALK MOUNT	1
5	47019213	END MTG BRACKET	2
6	47019212	TRANSPORT LOCK	2
7	47019211	SUPPORT CHAIN	4
8	47019202	SPACER BUSHING	12
9	47019217	BACKING WASHER	12
10	18475240	BOLT HX CAP 1/2-13 X 1 1/4 LG SS	12
11	18997400	HEX NUT, 1/2-13NC S.S.	12
12	18541430	CLEVIS PIN, 1/2 X 2	4
13	18560722	COTTER PIN, 5/32 X 1	4
14	18057426	BOLT, HX CAP 1/2-13 X 1 1/2 LG	12
15	18811400	WASHER, FLAT 1/2 ZC USS	8
16	18891400	WASHER, 1/2 LOCK ZC	12
17	18417400	NUT, HX 1/2 NC ZC	12


ALSO INCLUDED, BUT NOT SHOWN (SEE CATWALK SAFETY HARNESS PAGE)
CATWALK BOLT ON SAFETY BAR KIT (BASED ON TENDER)

CATWALK MOUNTING INSTRUCTIONS FOR 16 TON AND 24 TON TENDER BOX

- 1: Mount the catwalk on the left hand (driver side) of the tender box.
- 2: Position (1) end mounting bracket (item 5) so that the edge of the bracket is flush with the front edge of the box and so that the top set of holes are 10 inches (19" with extensions) from the top flange of the box. Using the bracket as a template, mark all 4 holes.
- 3: Repeat step 2 at the back edge of the box. Front and rear mounted brackets must be level with each other.
- 4: For the center bracket (item 4) To the center of the next bracket should be approximately 93 13/32 to 94 inches apart. Measure 94 inches from the center of the bracket nearest the edge of the box and mark this position. Measure 10 inches down from the top of the box (19" with extensions) and mark the center for the hole. Use the center bracket as a template and mark all 4 holes. Each mounting bracket (items 4 & 5) requires a 2 1/2 x 11 inch hole pattern.)
- 5: Mark hole pattern centers at 2 1/2 inches on ends and 90 29/32 apart. Inside hole centers should be 90 29/32 apart) Drill 17/32 diameter holes. Twelve for a 16 ton tender, sixteen for a 24 ton tender.
- 6: Mount each end bracket (item 5) with (4) bolts (item 10) and (4) nuts (item 11). When mounting the center brackets (item 4) position (4) flat washers (item 15) between the bracket and the outside of the box. Use (4) backing washers (item 9) on the inside of the box and mount with the bolts (item 10) and nuts (item 11). Install the above hardware finger-tight at this time.
- 7: Position the catwalk (item 1) to the front bracket and the center bracket on the box and mount with (2) clevis pins (item 12) and (2) cotter pins (item 13).
- 8: Position the catwalk (item 2 OR 3) to the center and rear bracket and mount with the clevis pins (item 12) and cotter pins (item 13). For a 24 ton tender mount three catwalks per steps 7 and 8.
- 9: You may securely fasten the brackets at this time.
- 10: Assemble a transport lock (item 6) to the first channel of each catwalk section. If the access ladder is on the front of the box this would be the front channel. If the ladder is on the back this would be the rear channel. The transport lock should be located on the outside of the leg of the channel and the handle should be pointing towards the ladder. Position the bushing (item 8) in the slots in the transport lock and position the hardware so that the head of the bolt (item 14) and the flat washer (item 15) are next to the transport lock and the lock washer (item 16) and the nut (item 17) are next to the channel on the catwalk. Securely tighten the hardware.
- 11: Assemble the support chains (item 7) to the catwalk and the brackets with the spacers (item 8) and bolts (item 14) and lockwashers (item 16) and nuts (item 17). Test fold and unfold the catwalks to insure proper function.
- 12: CAUTION !!! Make sure the catwalk is locked up into the transport position before moving the discharge auger. MOVING THE DISCHARGE AUGER WITH THE CATWALKS DOWN MAY CAUSE AUGER TO INTERFERE WITH CATWALKS.

CATWALK PLATFORM BOLT ON SAFETY INSTRUCTIONS (MT24)


FIG.1



SEE STEP 1

FOR UNITS EQUIPPED WITH HEARTLAND AG SYSTEMS ARCH DIVIDERS, STEP 1 IS NOT REQUIRED

1. APPLY PROTECTIVE SLEEVES, (P/N: 47007969) TO THE BASE OF COVER SUPPORT HOOPS, AS SHOWN IN FIG. 1.
2. MOUNT ONE OF THE SAFETY MTG BRKT (P/N: 47007965) TO A CENTER RIB SECTION AS SHOWN USING ONE PREDRILLED HOLE, AND DRILL THE REMAINING HOLE. SECURE WITH SUPPLIED NUTS, WASHERS AND BOLTS.
3. THREAD ONE OF THE SUPPLIED FLANGE NUTS ONTO SAFETY MTG BAR, (P/N: 47007968), AND PLACE IT INTO THE SAFETY MTG BRKT, PARTIALLY SECURE WITH OTHER FLANGE NUT AS SHOWN IN DIAGRAM 1-1.
4. THREAD THE SAFETY MTG BAR, THROUGH THE SUPPORT HOOPS AS SHOWN IN FIG. 1, MOUNT THE PLATE UNTO THE TENDER BOX USING THE EXISTING HOLE, AND SUPPLIED BOLT AND NUT.
- ON UNITS WITH ARCH DIVIDERS, THE MTG BAR WILL PASS THRU PRECUT HOLES IN THE DIVIDER
5. THREAD ONE FLANGE NUT ONTO EACH END OF SAFETY MTG BAR DUAL (P/N:47007967), PLACE ONE END INTO THE MOUNTED SAFETY MTG BRACKET, PARTIALLY SECURE WITH ANOTHER FLANGE NUT.
6. THREAD THE DUAL BAR OVER THE COVER SUPPORT HOOP, PLACE REMAINING SAFETY MTG BRACKET ONTO THE DUAL BAR AND MOUNT TO TENDER USING ONE PREDRILLED HOLE AND DRILL THE REMAINING HOLE. SECURE WITH SUPPLIED NUTS AND BOLTS PARTIALLY SECURE REMAINING END OF THE DUAL BAR WITH ANOTHER FLANGE NUT.
- ON UNITS WITH ARCH DIVIDERS, THE MTG BAR WILL PASS THRU PRECUT HOLES IN THE DIVIDER
7. REPEAT STEPS 3-4 WITH REMAINING SIDE
8. FINISH BY TIGHTENING THE FLANGE NUTS SECURING THE MTG BARS TO THE MTG BRKTS SO THAT THE LANYARD FROM THE SAFETY HARNESS KIT,(P/N:47997965) WILL PASS OVER THE HOOPS.
- ON UNITS WITH THE ARCH DIVIDERS YOU WILL HAVE TO MOVE THE SAFETY STRAP BETWEEN SECTIONS.




CATWALK SAFETY HARNESS KIT - P/N: 47997965 (NOT INCLUDED/PURCHASED SEPARATELY)			
_____	SAFETY MTG BAR DUAL P/N: 47007967 QTY - 1	⊘	SAFETY MTG BRKT P/N: 47007965 QTY - 2
_____	SAFETY MTG BAR P/N: 47007968 QTY - 2		PROTECTIVE SLEEVE P/N: 47007969 QTY - 5
			SAFETY DECAL P/N: 699125 QTY - 2

FOR UNITS USING THE 7" HIGH HEARTLAND AG SYSTEMS ARCH DIVIDER USES SAFETY BRACKET P/N: 47003694 INSTEAD OF SAFETY MOUNTING BRACKET P/N: 47007965 (7" HIGH ARCH DIVIDER ONLY)

****IMPORTANT** - WHEN USING HOOPS, THE HOOP MUST BE LOCATED NEAR THE SAFETY BRACKET TO PREVENT DAMAGE TO THE TARP.**

CATWALK SAFETY HARNESS LAYOUT

CSHLO
REV 9/11/23



(ITEM #7 NOT SHOWN)

INCLUDED BUT NOT SHOWN BEGINNING FALL 2023
 1 - CATWALK SAFETY HARNESS KIT - P/N: 47997965
 (INCLUDES HARNESS P/N: 1161542 AND LANYARD P/N: 3100510)

MT16 KIT	MT24 KIT	MT32 KIT	ITEM #	PART #	DESCRIPTION
2	2	4	1	47007968	SAFETY MTG BAR
-	1	-	2	47007967	SAFETY MTG BAR (DUAL)
3	5	6	3	47007969	PROTECTIVE SLEEVE (SEE NOTE 1)
1	2	2	4	47007965	SAFETY MTG BRKT (SEE NOTE 2)
4	6	8	5	18706621	BOLT, TRUSS SLOTTED 3/8-16 X 3/4 LG. SS
8	14	16	6	18987900	NUT, SER. FLG 3/8 S.S.
2	2	2	7	699125	SAFETY DECAL
4	6	8	8	18824800	WASHER, FLAT 1/2 S.S.
4	6	8	9	18991200	WASHER, FLAT 3/8 S.S.

NOTES:

- 1.) ON UNITS WITH THE HEARTLAND AG SYSTEMS ARCH DIVIDERS ITEM 3 (PROTECTIVE SLEEVE), IS NOT USED.
- 2.) FOR UNITS USING THE 7" HIGH HEARTLAND AG SYSTEMS ARCH DIVIDER USES SAFETY BRACKET P/N: 47003694 INSTEAD OF SAFETY MOUNTING BRACKET P/N: 47007965 (7" HIGH ARCH DIVIDER ONLY)

INSTALLATION QUESTIONS?




CALL THE SHUR-LOK CUSTOMER SERVICE HELP LINE!

1-866-SHUR-HELP

(1-866-748-7435)


or download Installation Instructions at
www.shurco.com

We take pride in designing our products to more than meet your expectations. All our products are made to be as convenient and easy to install as possible. However, should you have any questions at all, please call our free Customer Service Help Line. Your system performance and satisfaction depend on it. Our Customer Service Help Line is available from 8 a.m. to 5 p.m. Monday thru Friday. We can also do your installation at one of our eight Service Centers across the U.S. Call for your nearest location or go to www.shurco.com.



See your Shur-Lok owners manual
for complete installation instructions

SHUR-LOK FARM & SEMI REPLACEMENT PARTS



REPLACEMENT PARTS LIST

Item	Part #	Description
1	1100169	Stretch Cord, 138"
2	1107680	Roll Return Cord Cover, 6"
3	1100138	Roll Return End Plug, 2"
4		Aluminum Front Cap
5	1107009	Single Bow Bracket
6	1100749	Side Mount Latch Plate, 4'-0"
	1700522	Side Mount Latch Plate, 8'-0"
	1700802	Side Mount Latch Plate, 6'-0"
7	1100033	Crank Retainer, 7" Stand-Off
8	1107049	Pinless Crank Retainer
9	1100306	Bushing, 11/16" x 5/16"
10	1101683	Bushing, 1/2" x 1/4"
11	1101678	Ratchet w/Ridge Strap & Anchor
12	1100760	Bow, Low Rise, Standard
13	1101680	Ridge Strap & Anchor Assy, 1" x 25'-0"
14	1100165	Trim Seal, 110"
15	1100182	Shur-Lok Decal
16		Aluminum Back Cap
17	1100695	Bow Shank, 3/4" x 108"
18	1108568	Roll Return Pipe, 1/2 Sch 40 x 5', Belled
19	1100168	Roll Return Pipe, 1/2 Sch 40 x 5'
20	1107058	Roll Tube w/ Splined Shaft, 2" x
21	1701354	Plastic U-Clamp
22	1701243	Splined U-Joint
23	1700526	Wire Lock Pin, 3/8" x 2 1/2"
24	1100028	Crank Extension w/Insert, 80"
25	1100171	Crank Arm, Standard
26	1700523	End Plug, 1 1/8" OD
27		Shur-Lok Tarp
28	1700049	Swaged Tubing, 1 1/8" x 20'-03"
29	1100049	Tarp Stop, Standard
30	1700729	Protective Cap

HARDWARE LIST

Item	Part #	Description
A	1701423	Set Screw, #10 x 3/16"
B	1700084	Self-Tapping Screw, #8 x 3/8"
C	1700736	Self-Tapping Screw, 1/4" x 1/2"
D	1700398	Self-Drilling Screw, 1/4" x 3/4"
E	1701059	Self-Tapping Screw, 5/16" x 1"
F	1700400	Self-Tapping Screw, 3/8" x 1"
G	1700369	Cap Screw, 3/8" x 1 3/4"
H	1700411	Hex Nut, 5/16"
J	1700419	Nylon Lock Nut, 5/16"
K	1700407	Hex Nut, 3/8"
L	1700418	Centerlock Nut, 3/8"
M	1702996	Cap Screw, 1/2" x 1 1/4"
N	1700717	Eyebolt, 5/16"
P	1700433	Lock Washer, 5/16"
R	1700434	Lock Washer, 3/8"
S	1703373	Flat Washer, 1/2"
T	1701176	Flat Washer, 3/8"
U	1700474	Drive Rivet, 1/4" x 3/4"
V	1701118	Spring Pin, 1/4" x 1 3/16"
W	1700443	Spring Pin, 3/8" x 2"

(see Hardware Identification on page 1).

56



57


HELPLINE 1-866-748-7435

MT24 VIBRATOR INSTALLATION INSTRUCTIONS

(MARTIN ENGINEERING VIBRATORS [NOV. 2018 AND NEWER])



P/N: 4703DC700 (LOOSE)

P/N: 4703DC700A (INSTALLED)



DETAIL A
SCALE 1 : 6


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	MT24 WITH FENDERS	MT24 W/ FENDERS ASSEMBLY	1
2	47007997	VIBRATOR MOUNT	3
3	MDCV12-700-MM-96-06	VIBRATOR	3
4	18704218	SCREW MACH RD PH SS 8-32 X 3/4 LG	12
5	18474201	NUT HX NYLOCK #8-32 SS	12
6	18097540	BOLT, HEX CAP 1/2-13 X 4 1/2 LG GRADE 8 ZC	6
7	18457400	NUT, NYLOCK 1/2-13 GRADE 8 ZC	6
8	18851400	WASHER FLAT 1/2 SAE ZC	6
9	72383	VIBRATOR SWITCH BACK PLATE	3
10	CG-100451	SWITCH (INCLUDED WITH VIBRATOR)	3
11	195569-86	CORD EXTENSION 86" (INC. W/ VIBRATOR)	3
12	735230	TRAILER WIRE 12GA/2	NOTE
ALSO REQUIRED BUT NOT SHOWN			
	32504	VINYL INSULATED RING	3
	38262	STEP DOWN BUTT CONNECTORS	3
ITEM 1 IS SHOWN FOR REFERENCE ONLY			





MT24 VIBRATOR INSTALLATION INSTRUCTIONS

(MARTIN ENGINEERING VIBRATORS [NOV. 2018 AND NEWER])


**REPLACEMENT PARTS
CG-100454 - FUSE 20 AMP**



VIBRATORS ONLY



DETAIL B
SCALE 1 : 10




REAR VIEW OF TENDER
(CENTER PAD ON BOX)

1. CABLES MARKED "A" ARE PREASSEMBLED TO THE VIBRATOR
2. ATTACH P/N: 38262 (STEP DOWN BUTT CONNECTOR) TO CONNECTOR
3. INSERT CUT TO LENGTH WIRE (P/N:735320) INTO THE OPEN END OF THE BUTT CONNECTOR AND SEAL
4. REPEAT FOR ALL VIBRATORS
5. SEND P/N: 32504 (VINYL INSULATED RINGS) LOOSE


MT24 VIBRATOR PART LIST

(AVAILABLE FOR 6 COMPARTMENT UNITS ONLY)

P/N: 4703DC700




DETAIL C
SCALE 1 : 10



ALSO REQUIRED, BUT NOT SHOWN:
18000040 - 14-4 SO CORD - 13'
20046 - WIRE 6 GA 2 STRAND - 25'
6062 - WIRE 14 GA 2 STRAND - 17'

DETAIL D
SCALE 1 : 10



VIBCO VIBRATORS
PRE NOVEMBER 2018
MODELS ONLY


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	mt24 with fenders	MT24 W/ FENDERS ASSEMBLY	1
2	47003461	REAR MOUNTING PLATE	1
3	47003464	MOUNTING PLATE	1
4	18000043	SCEPTER JBX 8X8X4 (COVER NOT SHOWN)	1
5	18000042	SCEPTER JBX 4X4X4 (COVER NOT SHOWN)	1
6	47007997	VIBRATOR MOUNTING PAD	3
7	DC-700	VIBRATOR	3
8	77002	4-PORT SOLENOID	3
9	18000049	SELECTRA SWITCH SS206A-BG	3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
10	18000046	SELECTRA SWITCH SSAN105	3
11	N/A	WIRE CAP (SHOP SUPPLIES)	1
12	N/A	FUSE (SHOP SUPPLIES)	1
13	18000041	1/2 CGB CG5050	3
14	18000048	CORD GRIP CG5050S	3
15	18000050	BOLT AH SS 1/4 X 3/4	6
16	18569200	NUT 1/4 NYLOCK SS	17
17	18025718	BOLT CAP SS 1/4 X 3/4	11
18	18881001	WASHER FLAT 1/4 SS	11
19	18056854	BOLT HX CAP G5 NC ZC 3/8 X 5	2
20	18566400	NUT SS NYLOCK 3/8	2

MT24 VIBRATOR CONNECTON DIAGRAM

P/N:4703DC700


LETTER	DESCRIPTION
F	FUSE WIRE
G	GROUND WIRE
P	POWER WIRE
R	RETURN WIRE
MP	MAIN POWER
SG	SWITCH GROUND
SP	SWITCH POWER
VG	VIBRATOR GROUND
VP	VIBRATOR POWER




A

- NOTES:
 1. GROUND WIRES - BLACK
 2. POWER WIRE - WHITE
 3. THERE IS 1 BUTT CONNECTOR ON THE RETURN LINE

**VIBCO VIBRATORS
 PRE NOVEMBER 2018
 MODELS ONLY**




**DETAIL B
 SCALE 1 : 5**



**DETAIL A
 SCALE 1 : 5**

ARCH DIVIDER LAYOUT & PARTS LISTING

(MT16 - MT24 - MT32)



ITEM NO.	PART #	DESCRIPTION	QTY
1	N/A	DIVIDER PANEL(ON TENDER)	N/A
2	SEE CHART	BOW DIVIDER	1
3	18706621	SCREW, SLOTTED TRUSS HEAD 3/8 X 3/4 S.S.	5
4	18987900	NUT, SER. FLG. S.S. 3/8	5

BOLT KIT P/N: 47883641 CONTAINS ITEMS 3 AND 4

BOW ONLY PART NO.	BOW W/ HARDWARE PART NO.	FITS UNIT
47003641	47993641	MT 16/24/32 (12" HIGH ARCH)
47003691	47993691	MT 16/24/32 (7" HIGH ARCH)


DIVIDERS ARE ORDERED INDIVIDUALLY

AUGER WARNING SYSTEM


PART #: 70660

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	70875	ALARM BOX	1
2	70878	CORDGRIP	3
3	70877	FEMALE BULKHEAD CONNECTOR WITH NUT	1
4	70876	STOP LIGHT SWITCH	1
5	70879	1/4" X 1" SELF TAPPING SCREW, SS, DRILL TIP	4
6	70880	UNION TEE, 3/8	1
7	70881	LIMIT SWITCH	1
8	70656	RING TERMINAL, HEAT SHRINK, 16-14 GA AND #10 SCREW SIZE	2
9	70882	IN LINE FUSE HOLDER	1
10	70883	RING TERMINAL, HEAT SHRINK, 16-14 GA AND 3/8" SCREW SIZE	2
11	70884	AIR BRAKE TUBING	8'
12	70886	SPLICE CONNECTOR, 16-14 GA, HEAT SHRINK	3
13	70887	ALARM	1
14	70875-2	ALARM BOX COVER (INCLUDED W/ ALARM BOX)	1
15	18055718	BOLT HX 1/4 X 3/4	2
16	18881001	WASHER FLAT 1/4 SS	2
17	18569200	NUT 1/4 NYLOCK SS	2
18	70888	FUSE, 7.5A	1
19	70885	PORTABLE CORD	50'
20	70658	ADHEASIVE BACKED CABLE TIE HOLDER, OUTDOOR	12
21	71043	NUT, NYLOCK, 10-24, SS	2
22	71044	SCREW, PAN HEAD, 10-24 X 1-3/4", SS	2
23	70659	CABLE TIE, 7-1/2" LONG, OUTDOOR	12

MT16, MT24, AND MT32 MOUNTING LOCATIONS




LOCATE SWITCH AS SHOWN ON AUGER CRADLE SO THAT THE TOGGLE ARM IS TRIGGERED WHEN AUGER IS SEATED IN CRADLE. AN AUDIBLE CLICK CAN BE HEARD WHEN THE SWITCH IS TRIGGERED.



NOTCH OUT AREA OF AUGER CRADLE SO TOGGLE CAN MOVE FREELY. NOTCH DIMENSION APPROXIMATELY 6" X 1".


MATCH DRILL HOLES FOR SWITCH AND ATTACH USING ITEMS 21-22.

SECURE WIRE USING CABLE TIES AND CABLE TIE MOUNTS ALONG BODY/FRAME OF TENDER




OPTIONAL BOLT ON POKE HOLE & FLUSH TUBE P/N: 71850

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	71849	POKE HOLE/FLUSH TUBE WELDT	1
2	200A	BANJO 2" CAM LEVER COUPLING, MALE ADAPTER FEMALE THREADS	1
3	200172	2" FEMALE COUPLER CAP	1




REPLACES:

SIGHT GLASS
P/N: 76608



PORT HOLE FRAME
P/N: 76609



ORDER 1 PER WINDOW TO BE REPLACED

SECURE USING THE HARDWARE REMOVED FROM WINDOWS

(18026422 - BOLT CAP SS 5/16 X 1 - QTY 7 (8 WILL BE REMOVED))

(18476351 - NUT HX SS 5/16 SELF LOCK QTY 8)

